

DXM150-Sx Wireless Modbus Slave

Instruction Manual

Original Instructions
195455 Rev. B
13 July 2018
© Banner Engineering Corp. All rights reserved



195455

Contents


1 DXM150-Sx Overview	4
1.1 DXM150-Sx Wireless Modbus Slave System Overview	4
1.2 DXM Configuration Tool Overview	4
2 DXM150-Sx Hardware Overview	5
2.1 DXM Hardware Configuration Overview	5
3 ISM Radio	6
3.1 ISM Radio Board (Modbus Slave ID 1)	6
3.1.1 DIP Switch Settings for the MultiHop HE5 Board Module	7
3.2 Binding the ISM Radio of a DXM150-Sx Wireless Modbus Slave	8
4 I/O Base Board for the DXM150-S1 Model	9
4.1 Board Connections	9
4.1.1 DIP Switches for the I/O Board	10
4.1.2 I/O Board Jumpers	10
4.2 Applying Power to the DXM150-Sx Wireless Modbus Slave	10
4.2.1 Supplying Power from a Solar Panel	10
4.2.2 Connecting a Battery to the DXM Modbus Slave	11
4.3 Working with Solar Power	12
4.3.1 Setting the DXM Modbus Slave for Solar Power	12
4.3.2 Solar Components	12
4.3.3 Recommended Solar Configurations	13
4.3.4 Monitoring Solar Operation	14
4.4 Connecting the Communication Pins	14
4.5 Inputs and Outputs	15
4.5.1 Isolated Discrete Inputs	15
4.5.2 Relay Outputs	16
4.5.3 NMOS Outputs	16
4.5.4 Analog Outputs (DAC)	16
4.5.5 Universal Inputs	17
4.5.6 Modbus Registers	19
4.6 Setting the Modbus Slave ID on the I/O Base Board	21
4.6.1 DXM150-Sx Wireless Modbus Slave Models	21
4.6.2 Setting the DXM I/O Board Modbus Slave ID using Modbus Registers	21
4.6.3 I/O Board Jumpers	21
5 I/O Base Board for the DXM150-S2 Models	23
5.1 Board Connections	23
5.1.1 DIP Switches for the I/O Board	24
5.1.2 I/O Board Jumpers	24
5.2 Applying Power	24
5.2.1 Supplying Power from a Solar Panel	25
5.2.2 Connecting a Battery to the DXM Modbus Slave	26
5.3 Working with Solar Power	26
5.3.1 Setting the DXM Modbus Slave for Solar Power	26
5.3.2 Solar Components	26
5.3.3 Recommended Solar Configurations	27
5.3.4 Monitoring Solar Operation	28
5.4 Connecting the Communication Pins	28
5.5 Inputs and Outputs	29
5.5.1 Universal Inputs	29
5.5.2 PNP and NPN Outputs	31
5.5.3 Analog Outputs (DAC)	31
5.5.4 Isolated Discrete Inputs	32
5.5.5 Modbus Registers	32
5.6 Setting the Modbus Slave ID on the I/O Base Board	35
5.6.1 DXM150-Sx Wireless Modbus Slave Models	35
5.6.2 Setting the DXM I/O Board Modbus Slave ID using Modbus Registers	35
5.7 Restoring Factory Default Settings	35
6 Restoring Factory Default Settings	37
7 DXM150 Dimensions	38
8 Accessories	39
9 Additional Information	40
9.1 DXM150 Documentation List	40
9.2 DXM Modbus Slave Support Policy	40
9.2.1 Firmware Updates	40

9.2.2 Website Information	40
9.2.3 Feature Requests	40
9.2.4 Potential DXM Issues	40
9.2.5 DXM Security	41
9.3 Contact Us	41
10 Warnings	43
10.1 Banner Engineering Corp. Limited Warranty	43

1 DXM150-Sx Overview

1.1 DXM150-Sx Wireless Modbus Slave System Overview

Banner's DXM Logic Controller integrates Banner's wireless radio and local I/O for a remote I/O device.



Inputs/Outputs—On-board universal and programmable I/O ports connect to local sensors, indicators, and control equipment.

- Universal Inputs
- Discrete outputs
- Courtesy power
- Switch power
- Battery backup
- Solar controller

Connectivity—The integrated Sure Cross® wireless radio enables Modbus connectivity to remote sensors, indicators, and control equipment.

Wired Connectivity

Field Bus: Modbus RS-485 Master

Wireless Connectivity


Sure Cross MultiHop 900 MHz, or MultiHop 2.4 GHz

1.2 DXM Configuration Tool Overview

The DXM Configuration Tool configures the DXM Modbus Slave by creating an XML file that is transferred to the DXM Modbus Slave using a USB or Ethernet connection. The DXM Modbus Slave can also receive the XML configuration file from a Web server using a cellular or Ethernet connection.

This configuration file governs all aspects of the DXM Modbus Slave operation. The wireless network devices are a separate configurable system. Use the DX80 User Configuration Tool (UCT) to configure the internal DX80 wireless Gateway and the attached wireless Nodes. Use the MultiHop Configuration Tool (MCT) if the internal radio is a MultiHop device.

All tools can be connected to the DXM Modbus Slave using a USB cable or an Ethernet connection.




2 DXM150-Sx Hardware Overview

2.1 DXM Hardware Configuration Overview

The DXM Modbus Slave can have multiple configurations. The DXM Modbus Slave will have a model number label on the housing. Use the model number and model table above to identify which boards are included in the controller.

When opening the DXM Modbus Slave, follow proper ESD grounding procedures. Refer to the ESD warning in the appendix.



The DXM Modbus Slave I/O base board provides connections for all inputs, outputs and power. The base board also contains a 12 V solar controller that accepts connections to a solar panel and SLA battery. The battery connection can also be used with line power to provide a battery backup in case of line power outages.

The ISM radio fits on the base board in the parallel sockets. Install the ISM radio so the U.FL antenna connection is to the side with the SMA antenna connectors. Connect the U.FL cable from the ISM radio U.FL to the right side U.FL connector. The ISM radio boards are available with either a 900 MHz radio or a 2.4 GHz radio.

3 ISM Radio

3.1 ISM Radio Board (Modbus Slave ID 1)

The ISM embedded radio boards are available in either DX80 MultiHop or DX80 Performance.


The DX80 MultiHop architecture creates a tree network with a Master radio and one or more Repeater/Slave devices. The MultiHop architecture is suited for networks requiring repeater devices to provide extended range or obstacle avoidance. MultiHop ISM radio devices are defined with R2, R4, and R5 in the model number.

- DXMxxx-xxR2 - MultiHop 900 MHz
- DXMxxx-xxR4 - MultiHop 2.4 GHz
- DXMxxx-xxR5 - MultiHop 900 MHz, 100 mW
- DXMxxx-xxR9 - MultiHop 900 MHz, (Australia)

The DX80 Performance architecture is a star-based architecture with one Gateway radio and 1 to 47 Node devices. The Nodes communicate with the Gateway in a time slot method that is very predictable. DX80 Performance Gateway ISM radio devices are defined with R1, R3, and R8 in the model number.

- DXMxxx-xxR1 - DX80 Performance 900MHz
- DXMxxx-xxR3 - DX80 Performance 2.4GHz
- DXMxxx-xxR8 - DX80 Performance 900MHz (Australia)

The settings outlined below are specific for the DXM Modbus Slave. Not all selections are possible with the DXM Modbus Slave.



Plug the ISM radio into the I/O base board with the U.FL antenna connector closest to the SMA connectors.

- A - Antenna connector
- B - Button
- C - LED
- D1 - DIP switches
- D2 - DIP Switches

Button Operation

For DXM models without a LCD display, use the button (B) to bind the ISM radio. For models with a LCD display, use the ISM menu to bind the radio.

LED Operation

The LED located on the ISM radio module indicates power and communications traffic.

- Solid green DX80 ISM radio LED: Indicates power.
- Flashing green MultiHop ISM radio LED indicates operation.
- Red and green combined: Communications traffic and binding.

ISM board LED operations also display on the LED on the right side of the I/O base board.

3.1.1 DIP Switch Settings for the MultiHop HE5 Board Module

Device Settings	D1 Switches				D2 Switches			
	1	2	3	4	1	2	3	4
Serial line baud rate 19200 OR User defined receiver slots	OFF*	OFF*						
Serial line baud rate 38400 OR 32 receiver slots	OFF	ON						
Serial line baud rate 9600 OR 128 receiver slots	ON	OFF						
Serial line baud rate Custom OR 4 receiver slots	ON	ON						
Parity: None			OFF*	OFF*				
Parity: Even			OFF	ON				
Parity: Odd			ON	OFF				
Disable serial (low power mode) and enable the receiver slots select for switches 1-2			ON	ON				
Transmit power 900 MHz radios: 1.00 Watt (30 dBm) 2.4 GHz radios: 0.065 Watts (18 dBm) and 60 ms frame					OFF*			
Transmit power 900 MHz radios: 0.25 Watts (24 dBm) 2.4 GHz radios: 0.065 Watts (18 dBm) and 40 ms frame					ON			
Application mode: Modbus						OFF*		
Application mode: Transparent						ON		
MultiHop radio setting: Repeater							OFF*	OFF*
MultiHop radio setting: Master							OFF	ON
MultiHop radio setting: Slave							ON	OFF
MultiHop radio setting: Reserved							ON	ON

* Default configuration

Application Mode

The MultiHop radio operates in either Modbus mode or transparent mode. Use the internal DIP switches to select the mode of operation. All MultiHop radios within a wireless network must be in the same mode.

Modbus mode uses the Modbus protocol for routing packets. In Modbus mode, a routing table is stored in each parent device to optimize the radio traffic. This allows for point to point communication in a multiple data radio network and acknowledgement/retry of radio packets. To access a radio's I/O, the radios must be running in Modbus mode.

In **transparent** application mode, all incoming packets are stored, then broadcast to all connected data radios. The data communication is packet based and not specific to any protocol. The application layer is responsible for data integrity. For one to one data radios it is possible to enable broadcast acknowledgement of the data packets to provide better throughput. In transparent mode, there is no access to the radio's I/O.

Baud Rate and Parity

The baud rate (bits per second) is the data transmission rate between the device and whatever it is physically wired to. Set the parity to match the parity of the device you are wired to.

Disable Serial

If the local serial connection is not needed, disable it to reduce the power consumption of a data radio powered from the solar assembly or from batteries. All radio communications remain operational.

Transmit Power Levels/Frame Size

The 900 MHz data radios can be operated at 1 watt (30 dBm) or 0.250 watt (24 dBm). For most models, the default transmit power is 1 watt.

For 2.4 GHz radios, the transmit power is fixed at 0.065 watt (18 dBm) and DIP switch 5 is used to set the frame timing. The default position (OFF) sets the frame timing to 60 milliseconds. To increase throughput, set the frame timing to 40 milliseconds.

Prior to date code 15341 and radio firmware version 3.6, the frame timing was 40 ms (OFF) or 20 ms (ON).

3.2 Binding the ISM Radio of a DXM150-Sx Wireless Modbus Slave

A DXM150-Sx Wireless Modbus Slave (model DXM1x0-S*R2) contains two boards: a MultiHop ISM radio and an I/O base board. Each board is a separate Modbus device.

- The ISM radio is not required to have a Modbus ID because there are no registers to manage.
- The I/O board must have a Modbus ID to access the I/O register data and configuration data.

To bind the DXM150-Sx Wireless Modbus Slave (as either a repeater or slave radio) to its master radio, follow the binding instructions. If the binding instructions are not included in the master radio datasheet, refer to the MultiHop Quick Start Guide (p/n [152653](#)) or Instruction Manual (p/n [151317](#)).

The ISM radio board's Modbus ID is assigned from the master radio during binding using the master radio's rotary dials or the DXM Controller's LCD Binding menu. For example, if the master's binding number is 25, the DXM Slave ISM radio's Modbus ID is set to 25. To reduce the number of Modbus IDs used, set the ISM radio Modbus ID to 01.

By default, the I/O board's Modbus ID is set to 11. To change the Modbus ID, use the I/O board DIP switches. For applications requiring Modbus IDs outside the range of the DIP switches, write a Modbus ID to a Modbus register on the I/O board.

Use the MultiHop Configuration Tool to display and configure a MultiHop radio network. With the DXM150-Sx Wireless Modbus Slave, only the ISM radio displays on the Network View screen. The Modbus ID of the I/O board is a separate device that is not a part of the radio network. Although the I/O board does not show up in the Network View, it is accessible when using the Register View functions.

4 I/O Base Board for the DXM150-S1 Model

4.1 Board Connections




Figure 1. Board Connections

1	NC	17	Input 2B	33	Analog Output 1 (0 to 10 V)
2	12 to 30 V dc or solar power in (+)	18	Ground	34	Ground
3	Ground	19	Output 1 Normally Open	35	PWR Out - Jumper
4	Battery in (< 15 V dc) (must be a sealed lead acid battery)	20	Output 1 Common	36	Ground
5	Ground	21	Output 1 Normally Closed	37	Universal Input 8
6	Primary RS-485 -	22	Output 3 Normally Open	38	Universal Input 7
7	Primary RS-485 +	23	Output 3 Common	39	Universal Input 6
8	Ground	24	Output 3 Normally Closed	40	Universal Input 5
9	Not used	25	NMOS Output 5	41	Ground
10	Not used	26	No connection	42	Universal Input 4
11	Not used	27	NMOS Output 6	43	Universal Input 3
12	Not used	28	NMOS Output 7	44	Ground
13	Ground	29	No connection	45	PWR Out - Jumper
14	Input 1A	30	NMOS Output 8	46	Universal Input 2
15	Input 1B	31	Ground	47	Universal Input 1
16	Input 2A	32	Analog Output 2 (0 to 10 V)	48	Ground

A	Base Board LED	E	PWR Out Jumpers	G3	Analog Output Characteristics Jumpers (Jumper 1 sets analog out 1, jumper 2 sets analog out 2)
B	Not Used	F	Radio Binding Button	H	ISM Radio Connection
C	Radio LED	G1	Not Used	J	Modbus Slave ID DIP Switches
D	Radio Module Antenna	G2	Not Used	K	Rotary Dials
				L	SAM4 Processor Board Connection

4.1.1 DIP Switches for the I/O Board

The DXM150-Sx Wireless Modbus Slave I/O board DIP switches are set from the factory to Modbus Slave ID 11. For more information, refer to *Setting the Modbus Slave ID on the I/O Base Board*.

4.1.2 I/O Board Jumpers

Hardware jumpers on the DXM I/O board allow the user to select alternative pin operations. Turn the power off to the device before changing jumper positions.

Jumper	Function	Positions
E	Courtesy power output	<p>Jumper 2 is the power jumper for pin 45. Jumper 1 is the power jumper for pin 35.</p> <ul style="list-style-type: none"> The pin 45 jumper selects 2.7 V when in the "a" position and 12 V battery in the "b" position. The pin 35 jumper selects 4.2 V when in the "a" position and device power on pin 2 in the "b" position.
G1	RS-485 Modbus Slave or RS-232 Flow Control	<p>Defines the operation of pins 11 and 12. Set the jumpers to use pins 11 and 12 as a secondary Modbus RS-485 slave port or flow control pins for the RS-232 port. Both jumpers must be set to the same operation, RS-485 Modbus Slave or Flow control.</p> <p>The default setting is RS-485.</p>
G2	Generic RS-232 Serial Port or CAN Serial Port	<p>Defines the operation of pins 9 and 10. Set the jumpers to use pins 9 and 10 as a CAN serial port or a generic RS-232 serial port. Both jumpers must be set to the same operation, CAN or RS232.</p> <p>The default setting is CAN serial port.</p>
G3	Analog output characteristics for AO2 (pin 32) and AO1 (pin 33)	<p>Defines current (0–20 mA) or voltage (0–10 V) for analog output 1 and 2.</p> <p>By default, current (0–20 mA) is selected using jumpers 1 and 2 and registers 4008 and 4028 contain a value of 2.</p> <p>To select voltage (0–10 V) for output Aout1, set jumper 1 in the voltage position (V) and set Modbus register 4008 on the I/O board (SID 200) to 3.</p> <p>To select voltage (0–10 V) for output Aout2, set jumper 2 in the voltage position (V) and set Modbus register 4028 on the I/O board (SID 200) to 3.</p>

4.2 Applying Power to the DXM150-Sx Wireless Modbus Slave

Apply power to the DXM150-Sx Wireless Modbus Slave using either 12 to 30 V dc or a 12 V dc solar panel and 12 V sealed lead acid battery.

Pin	Description
Pin 1	No connection
Pin 2	12 to 30 V dc input (+) or solar panel connection (+)
Pins 3, 5, 8, 13, 18, 31, 34, 36, 41, 44, 48	Main logic ground for the DXM150-Sx Wireless Modbus Slave
Pin 4	Solar or backup battery positive input. Battery voltage must be less than 15 V dc. Use only a sealed lead acid (SLA) battery.
Pin 35, Pin 45	<p>These outputs are controlled by hardware jumpers.</p> <p>Jumper 2 is the power jumper for pin 45. Jumper 1 is the power jumper for pin 35. Refer to the wiring board for more information.</p> <ul style="list-style-type: none"> The pin 45 jumper selects 2.7 V when in the "a" position and 12 V battery in the "b" position. The pin 35 jumper selects 4.2 V when in the "a" position and device power on pin 2 in the "b" position.

4.2.1 Supplying Power from a Solar Panel

To power the DXM150-Sx Wireless Modbus Slave from a 12 V dc solar panel, connect the solar panel to power pins 2(+) and 3(-). Connect a 12 V dc sealed lead acid (SLA) rechargeable battery to pins 4(+) and 5(-).

The factory default setting for the battery charging algorithm assumes you are using 12 to 30 V dc power to recharge the battery. If the incoming power is from a solar panel, you must change the charging algorithm.

To change the charging algorithm from the menu system:

1. From the DXM Modbus Slave LCD menu, navigate to **System Config > I/O Board > Charger**.
2. Select **Solar** for solar panel configurations.

To change the charging algorithm by writing to Modbus register 6071 on the I/O base board (Slave ID 11):

1. Write a 0 to select the solar power charging algorithm.

Modbus Slave ID	Modbus Register	Description
11 *	6071	Battery backup charging algorithm. 0 = Battery is recharged from a solar panel 1 = Battery is recharged from 12 to 30 V dc (default)

The following power operating characteristics are stored in Modbus registers.

Battery voltage

If no battery is present, the value in this register is less than 5 V. If the value in this register is greater than the incoming voltage register, the battery is powering the system.

Battery charging current

The charging algorithm charges the battery when the incoming voltage register value is greater than the battery voltage register value. This registers shows the charging current in milliamps.

Incoming supply voltage

The incoming power can be from a solar panel or from a power supply. The battery is charging when the incoming voltage register value is greater than the battery voltage register value. The battery is powering the system when the incoming voltage register value is less than the battery voltage register value.

On-board thermistor temperature

This register stores the on-board thermistor reading in tenths of degrees C, this is not a calibrated input: divide by 10 to calculate the temperature in degrees C. For calibrated temperature inputs, define one of the universal inputs as a temperature input.

Modbus Slave ID	Modbus Register	Description
11 *	6081	Battery voltage (mV)
	6082	Battery charging current (mA)
	6083	Incoming supply voltage (mV) (solar or power supply)
	6084	On-board thermistor temperature (°C)

* The Slave ID for the base board is set at the factory. This may be changed using the base board DIP switch settings.

4.2.2 Connecting a Battery to the DXM Modbus Slave

When attaching a battery to the DXM Modbus Slave as a backup battery or as a solar battery, verify the charging algorithm is set properly. The factory default setting for the battery charging algorithm assumes you are using 12 to 30 V dc to recharge the battery.

The charging algorithm is designed to work with a sealed lead acid (SLA) battery only.

- When using 12 to 30 V dc, connect the 12 to 30 V dc + to pin 2 and connect the ground to pin 3.
- When using main dc power with a back up battery (default configuration), connect the incoming main power pin 2 (+) and to pin 3 (-). Connect the 12 V sealed lead acid battery to pin 4 (+) and pin 5 (-). The incoming main power must be 15 to 30 V dc to charge the battery.
- When using a solar panel, connect the solar panel output to pin 2 and connect the ground to pin 3. Connect the 12 V dc SLA battery to pin 4 (+) and pin 5 (-). To change the charging algorithm, refer to [Supplying Power from a Solar Panel](#) on page 10.

The battery charging algorithm defaults to a battery backup configuration. To charge the battery from a solar panel, change the battery charging algorithm.

1. From the DXM Modbus Slave LCD menu navigate to **Setting Config > I/O Board > Charger**.
2. Select **Solar** for solar panel configurations or **DC** for battery backup configurations.

Modbus Slave ID	Modbus Register	Description
11 *	6071	Battery backup charging algorithm. 0 = Battery is recharged from a solar panel 1 = Battery is recharged from 12 to 30 V dc (default)

* The Modbus Slave ID for the base board is set at the factory and may be changed using the base board DIP switch settings.

4.3 Working with Solar Power

A reliable solar system requires careful planning and monitoring to size the components correctly. The recommendations provided are for the DXM Modbus Slave system as an autonomous system.

Adding extra components increases the power requirements and likely requires increasing the solar system components. Depending upon the geographical location, the size of the solar panel and battery may vary.

4.3.1 Setting the DXM Modbus Slave for Solar Power

By default, the DXM Modbus Slave is set from the factory to charge a backup battery from a line power source. Use the LCD menu on the front of the DXM Modbus Slave to change the charging algorithm to solar power.

Go to **System Config > I/O Board > Charger**. Use the up/down arrows to select **Solar**.

For DXM devices without an LCD, adjust the I/O board Modbus register 6071. Set the register to 0 to select battery charging from a solar panel, and set to 1 to select battery charging from incoming 12 to 30 V dc supply.

Here are a few DXM configuration tips to help minimize the power consumption (may not apply to all models).

- If Ethernet is not being used, save up to 25% of the consumed power by disabling Ethernet. Set DIP switch 1 to the ON position on the processor board then reboot.
- Instead of powering external devices all the time, take advantage of the switched power mechanisms to turn off devices when possible.
- Minimize the number of cellular transactions and the amount of data pushed across the cellular modem.

4.3.2 Solar Components

The components of a solar system include the battery and the solar panel.

Battery

The DXM solar controller is designed to use a 12 V lead acid battery. The characteristics of a solar system require the battery to be of a certain type. There are basically two types of lead acid batteries:

- SLI batteries (Starting Lights Ignition) designed for quick bursts of energy, like starting engines
- Deep Cycle batteries - greater long-term energy delivery. This is the best choice for a solar battery.

Since a solar system charges and discharges daily, a deep cycle battery is the best choice. There are different versions of a lead acid battery: wet cell (flooded), gel cell, and an AGM (absorbed glass mat).

Wet cell batteries are the original type of rechargeable battery and come in two styles, serviceable and maintenance free. Wet cell batteries typically require special attention to ventilation as well as periodic maintenance but are the lowest cost. The gel cell and AGM battery are sealed batteries that cost more but store very well and do not tend to sulfate or degrade as easily as a wet cell. Gel or AGM batteries are the safest lead acid batteries you can use.

Battery Capacity

Battery capacity is a function of the ambient temperature and the rate of discharge. Depending upon the specific battery, a battery operating at $-30\text{ }^{\circ}\text{C}$ can have as much as 40 percent less capacity than a battery operating at $20\text{ }^{\circ}\text{C}$. Choose enough battery capacity based on your geographical location.

A larger capacity battery typically lasts longer for a given solar application because lead-acid batteries do not like deep cycling (discharging a large percentage of its capacity). Depending upon the battery, a battery discharging only 30 percent of its capacity before recharging will have approximately 1100 charge/discharge cycles. The same battery discharging 50 percent of its capacity will have approximately 500 charge/discharge cycles. Discharging 100 percent leaves the battery with only 200 charge/discharge cycles.

Batteries degrade over time based on discharge/charge cycles and environmental conditions. Always monitor the battery system to obtain the best performance of the solar powered system.

Use this as a guide to the approximate state of charge and in determining when to apply conservation measures.

Average Voltage Readings Relative to Battery Change	
State of Charge (%)	Open Circuit Voltage
100	13.0 or higher
75	12.6
50	12.1
25	11.66
0	11.4 or less

Solar Panel

Banner solar panels come in two common sizes for the DXM Modbus Slave: 5 Watt and 20 Watt. Both panels are designed to work with the DXM Modbus Slave but provide different charging characteristics. Use the 5 watt panel for light duty operation and use the 20 watt panel when you require greater charging capabilities.

Solar Panel	Voltage	Current	Typical DXM Configurations
5 Watt	17 V	0.29 A	DXM slave controller, ISM radio, I/O base board
20 Watt	21 V	1 A	DXM Controller with ISM radio and Cellular modem

Photovoltaic panels are very sensitive to shading. Unlike solar thermal panels, PV solar panels cannot tolerate shading from a branch of a leafless tree or small amounts of snow in the corners of the panel. Because all cells are connected in a series string, the weakest cell will bring down the other cells' power level.

Good quality solar panels will not degrade much from year to year, typically less than 1 percent .

Solar Panel Mounting

To capture the maximum amount of solar radiation throughout the year, mount a fixed solar panel to optimize the sun's energy throughout the year. For the northern hemisphere, face the panel true south. For the southern hemisphere, face the panel true north. If you are using a compass to orientate the panels, compensate for the difference between true north and magnetic north. Magnetic declination varies across the globe.

A solar panel's average tilt from horizontal is at an angle equal to the latitude of the site location. For optimum performance, adjust the tilt by plus 15 degrees in the winter or minus 15 degrees in the summer. For a fixed panel with a consistent power requirement throughout the year, adjust the tilt angle to optimize for the winter months: latitude plus 15 degrees. Although in the summer months the angle may not be the most efficient, there are more hours of solar energy available.

For sites with snow in the winter months, the increased angle helps to shed snow. A solar panel covered in snow produces little or no power.

4.3.3 Recommended Solar Configurations

These solar panel and battery combinations assume direct sunlight for two to three hours a day. Solar insolation maps provide approximate sun energy for various locations. The depth of battery discharge is assumed to be 50 percent.

Solar panel and battery combinations for a DXM Modbus Slave system				
Solar Panel	Battery Capacity ¹	Days of Autonomy	DXM mA	DXM Controller
5 watt	10 Ahr	10 days	25 mA	DXM Slave Controller - ISM radio and I/O base board
20 watt	14 Ahr	10 days	30 mA	DXM Controller with ISM radio

¹ Battery capacity (amp hour) is standard amp rating taken for 20 hours. Battery capacity should be monitored for reliable system power and may need to be increased for cold weather locations.

Solar panel and battery combinations for a DXM Modbus Slave system				
Solar Panel	Battery Capacity ¹	Days of Autonomy	DXM mA	DXM Controller
20 watt	20 Ahr	10 days	35 mA	DXM Controller with ISM radio and Cellular Modem

4.3.4 Monitoring Solar Operation

The DXM solar controller provides Modbus registers that allow the user to monitor the state of the solar panel input voltage, the battery voltage, the charging current, and the temperature in °C. The DXM Modbus Slave can be configured to monitor the health of the charging system as well as send an alert message when the battery is too low.

The charts show a typical charging cycle, with each vertical grid representing about eight hours. The chart shows three days of charging.




Figure 2. Solar Panel Voltage (mV) -- Cloudy First Day




Figure 3. Battery Voltage (mV) - Cloudy First Day

4.4 Connecting the Communication Pins

The base board communications connection for external Modbus device uses the primary RS-485.

RS-485. The primary RS-485 bus is a common bus shared with the ISM radio board (Modbus Slave ID 1).

RS-232. The RS-232 bus is not currently defined.

Pin	Parameter	Description
Pin 6	Primary RS-485 -	Running Modbus protocol at 19.2k baud, use this bus to connect to other Modbus Slave devices. The DXM150-Sx Wireless Modbus Slave is a Modbus Master device on this RS-485 port.
Pin 7	Primary RS-485 +	Modbus Register 6101 = Baud Rate 0 = 19.2k 1 = 9600 2 = 38400 Modbus Register 6103 = Parity 0 = no parity 1 = odd? 2 = even?

¹ Battery capacity (amp hour) is standard amp rating taken for 20 hours. Battery capacity should be monitored for reliable system power and may need to be increased for cold weather locations.

Pin	Parameter	Description
Pin 9	RS-232 Tx	Serial RS-232 connection. This bus must use a ground connection between devices to operate correctly.
Pin 10	RS-232 Rx	
Pin 13	Secondary RS-485 -	Not used
Pin 14	Secondary RS-485 +	
Pin 15	CANL -	
Pin 16	CANH +	

4.5 Inputs and Outputs

The I/O base board is a Modbus slave device that communicates using Modbus commands. Refer to the Modbus Registers section for more descriptions of each Modbus register on the DXM150-Sx Wireless Modbus Slave.

4.5.1 Isolated Discrete Inputs

Pin	Input	Description	
Pin 14	Input 1A	Optically isolated AC input type, 0 to 12 to 30 V dc Input to output isolation of 2.5 kV	
Pin 15	Input 1B		
Pin 16	Input 2A		
Pin 17	Input 2B		

Synchronous Counters. An isolated input can be programmed to count the input signal transitions. When an input is enabled as a counter, the counter value is stored into two 16-bit Modbus registers for a total count of 32-bits (unsigned). To program an input to capture the edge transition counts, follow [Example: Configure Input 1 as a Synchronous Counter](#) on page 18.

The counters are synchronous because the inputs are sampled at a 10 ms clock rate. The input logic does not detect rising or falling edges, it samples the input every 10 ms to find level changes. The input signals must be high or low for more than 10 ms or the input will not detect transitions. Because most signals are not perfect, a realistic limit for the synchronous counter would be 30 to 40 Hz.

Universal inputs can also be configured as a synchronous counter. See the Modbus register map for universal inputs and all the register definitions. The procedure for creating a synchronous counter is the same as a isolated input with the addition of changing the input type to PNP or NPN.

Discrete Inputs	Modbus Registers for Counter Parameters	Register Definitions
Input 1	3013	Enable Rising
	3014	Enable Falling
	3015	Counter High
	3016	Counter Low
Input 2	3033	Enable Rising
	3034	Enable Falling
	3035	Counter High
	3036	Counter Low

4.5.2 Relay Outputs

Pin	Output	Description	Wiring
Pin 19	Output 1: Normally Open	SPDT (Form C) relay, 250 V ac, 16 A	
Pin 20	Output 1: Common		
Pin 21	Output 1: Normally Closed		
Pin 22	Output 3: Normally Open		
Pin 23	Output 3: Common		
Pin 24	Output 3: Normally Closed		

4.5.3 NMOS Outputs

Pin	Output	Description	Wiring
Pin 25	NMOS Discrete Outputs	Less than 1 A maximum current at 30 V dc ON-State Saturation: Less than 0.7 V at 20 mA ON Condition: Less than 0.7 V OFF Condition: Open	
Pin 27			
Pin 28			
Pin 30			

4.5.4 Analog Outputs (DAC)

The following characteristics are configurable for each of the analog outputs.

Pin	Output	Description
Pin 33	Analog Output 1	0 to 20 mA or 0 to 10 V dc output (I/O board jumper selectable) Accuracy: 0.1% of full scale +0.01% per °C Resolution: 12-bit
Pin 32	Analog Output 2	

Parameters for Analog Output 1 start at 4001 through 4008. Parameters for Analog Output 2 start at 4021 through 4028.

Parameter Registers for Analog Outputs (4xxxx)		
OUT 1	OUT 2	Parameters
4001	4021	Maximum Analog Value
4002	4022	Minimum Analog Value
4003	4023	Enable Register Full Scale
4004	4024	Hold Last State Enable
4005	4025	Default Output State
4008	4028	Analog Output Type

Analog Output Type. The analog outputs may be configured as either 0 to 20 mA outputs (default) or 0 to 10 V outputs. To change the analog output type change the hardware jumper position and write to the Modbus register that defines the analog output type. For analog output 1, write to Modbus register 4008, for analog output 2 write to Modbus register 4028. Write a value of 2 (default) to select 0 to 20 mA; write a value of 3 to select 0 to 10 V.

Default Output Conditions. Default output conditions/triggers are the conditions that drive outputs to defined states. Example default output conditions include when radios are out of sync, when a device cycles power, or during a host communication timeout.

- **2952 Enable Default Communication Timeout.** A “communication timeout” refers to the communication between any Modbus master host and the DXM baseboard. Set this register to 1 to enable the default condition when the host has not communicated with the DXM baseboard for the period of time defined by the Communication Default IO Timeout.
- **2953 Communication Default I/O Timeout (100 ms/Count).** This parameter defines the host timeout period in 100 millisecond increments. If a host does not communicate within this timeout period, the device outputs are set to the default values.
- **2954 Enable Default on Power Up.** Setting this parameter to 1 sends the device outputs to their default condition when the DXM baseboard is powered up. Set to 0 to disable this feature.

Default Output State. The Default Output State parameter represents the default condition of the analog output. When an error condition exists, the outputs are set to this 16-bit user-defined output state. To define the error conditions for device outputs, refer to the MultiHop default output parameters 2950-2954.

Enable Register Full Scale. Set to 1 to enable a linear range from 0 to 65535 for specified input range. For a 4 to 20 mA output, a value of 0 represents 4 mA and 65535 represents 20 mA. Set this parameter to 0 to store readings in unit-specific data. For example, the register data representing a 15.53 mA reading is 15530. For units of current (0 to 20 mA outputs), values are stored as μ A (micro Amps) and voltage values are stored as mV (millivolts).

Hold Last State Enable. Set the Hold Last State to 1 to set the output to its last known value before the error occurred. Set this parameter to 0 to disable the Hold Last State and use the Default Output State setting during an error condition.

Maximum Analog Value. The Maximum Analog Value register stores the maximum allowed analog value. The specific units of measure apply to the register value. For example, the register may contain 20000, for 20 mA, or for a voltage output the register may contain 8000, for 8 volts.

Minimum Analog Value. The Minimum Analog Value register stores the minimum allowed analog value. The specific units of measure apply to register value. For example, the register may contain 4000, for 4 mA, or for a voltage output the register may contain 2000, for 2 volts.

4.5.5 Universal Inputs

The universal inputs can be programmed to accept different types of inputs: discrete NPN/PNP, 0 to 20 mA analog, 0 to 10 V analog, 10k thermistor, potentiometer sense, bridge, and NPN raw fast. Use the DXM Configuration Tool tool to write to the appropriate Modbus registers in the I/O board to configure the input type.

The universal inputs are treated as analog inputs. When the universal inputs are defined as mA, V, or temperature, use Modbus registers to configure the operational characteristics of the inputs. These parameters are temperature conversion type, enable full scale, threshold and hysteresis. See the Modbus register section for the parameter definitions.

When a universal input is configured as an NPN or PNP input type, it can be enabled to be a synchronous counter. Enable the counter function by setting Modbus register 'Enable Rising' or 'Enable Falling' to 1. See *Modbus Registers* for the universal input register definitions.

Pin	Univ. Input	Description
Pin 47	Universal Input 1	Program the universal inputs to accept input types NPN, PNP, 10k thermistor, 0 to 10 V, 0 to 20 mA, or potentiometer. The default setting is 8: NPN raw fast. To set the input type, write the following values to the Input Type Modbus registers. 0 = NPN 1 = PNP 2 = 0 to 20 mA 3 = 0 to 10 V dc 4 = 10k Thermistor 5 = Potentiometer Sense (DXM150 only) 6 = Not used 7 = Bridge 8 = NPN Raw Fast (default)
Pin 46	Universal Input 2	
Pin 43	Universal Input 3	
Pin 42	Universal Input 4	
Pin 40	Universal Input 5	
Pin 39	Universal Input 6	
Pin 38	Universal Input 7	
Pin 37	Universal Input 8	

Thermistor Input. A thermistor input must use a 10k thermistor between ground and the universal input. The thermistor must be a 10K NTC (Banner model number BWA-THERMISTOR-002) or equivalent. Select the temperature conversion of degrees C (default) or degrees F by writing to the Modbus registers defined in *I/O Base Board*.

Potentiometer Sense (DXM150 only). A potentiometer input is created from two inputs: a voltage source (pin 45) that supplies a voltage to the potentiometer and an input sense (Potentiometer Sense) to read the resistance. Follow [Example: Change Universal Input 8 to Read a Potentiometer Input](#) on page 18 to configure the DXM150 Controller for a potentiometer input.

Potentiometer Input (DXM100 only). A potentiometer input is created from three inputs: a voltage source (pin 30) that supplies 5 V to the potentiometer and two inputs set to voltage inputs to read the voltage across the potentiometer. See the DXM technical note for setting up a potentiometer.

Bridge Input. The bridge input is not implemented yet.

NPN vs NPN Raw Fast. The difference between NPN and NPN Raw Fast is the amount of settling time given to the input. Switch the input type to NPN if the input is not detecting a transition.

Example: Configure Input 1 as a Synchronous Counter

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. In the **Write Registers** area, write Modbus register 4908 to 1 to enable counting on the rising edge of the input signal.
8. Read Modbus registers 4910 and 4911 to get the 32-bit value of the count.

Example: Change Universal Input 2 to a 0 to 10 V dc Input

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. Write a 3 to Modbus register 3326 on Modbus Slave ID 11 (I/O board).
8. Cycle power to the device.
9. Using the **Register View** tab, read register 3326 to verify it is set to 3.

Example: Change Analog Output 1 to a 0 to 10 V dc Output

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. Set jumper 1 on the I/O base board to the 0 to 10 V position. Refer to the base board image for the analog output jumper position.
8. Write a 3 to Modbus register 4008 on Modbus Slave ID 11 (I/O board).
9. Cycle power to the device.
10. Using the **Register View** tab, read register 4008 to verify it is set to 3.

Example: Change Universal Input 8 to Read a Potentiometer Input




Figure 4. Default jumper position

1. Launch the DXM Configuration Tool tool.
2. Click on the **Register View** tab on the left part of the page.
3. In the upper right part of the window select **Modbus Registers using Modbus Slave ID** radio button and enter Modbus Slave ID 11.

4. To set universal input 8 as the sense, write Modbus register 3446 with 5 (Potentiometer Sense).
5. Verify the jumpers are still set to their default position. One jumper should be on pins 1 and 3 to get a 2.7 V source voltage out pin 45. The default position of the other jumper is on pins 4 and 6.
6. Connect one potentiometer side to power output (pin 45), connect the tap point of the pot to universal input 8 (pin 37), and connect the other end of the pot to ground (pin 36).

4.5.6 Modbus Registers

The DXM MultiHop Modbus Slave device can have two Modbus Slave IDs: one for the MultiHop ISM radio (default 1) and one for the I/O base (default to 11). All Modbus registers are defined as 16-bit Modbus Holding Registers. When connecting additional Modbus slave devices, only use Modbus slave IDs 2 through 198.

Modbus Registers for the I/O Board

The I/O board slave ID is 11.

Base Board Input Connection		Base Board Output Connection	
Modbus Register	Description	Modbus Register	Description
1	Optically isolated input 1	501	Relay 1
2	Optically isolated input 2	502	Not used
3	Universal input 1	503	Relay 2
4	Universal input 2	504	Not used
5	Universal input 3	505	NMOS Output 5
6	Universal input 4	506	NMOS Output 6
7	Universal input 5	507	NMOS Output 7
8	Universal input 6	508	NMOS Output 8
9	Universal input 7	509	DAC Output 1
10	Universal input 8	510	DAC Output 2

Configuration Registers for the I/O Board

Register	Isolated Input A	Register	Isolated Input A
3013	Enable rising edge counter	3033	Enable rising edge counter
3014	Enable falling edge counter	3034	Enable falling edge counter
3015	High register for counter	3035	High register for counter
3016	Low register for counter	3036	Low register for counter

Universal Input Parameter Modbus Registers								
Universal Inputs	1	2	3	4	5	6	7	8
Enable Full Scale	3303	3323	3343	3363	3383	3403	3423	3443
Temperature °C/°F	3304	3324	3344	3364	3384	3404	3424	3444
Input Type	3306	3326	3346	3366	3386	3406	3426	3446
Threshold	3308	3328	3348	3368	3388	3408	3428	3448
Hysteresis	3309	3329	3349	3369	3389	3409	3429	3449
Enable Rising	4908	4928	4948	4968	4988	5008	5028	5048


Universal Input Parameter Modbus Registers								
Universal Inputs	1	2	3	4	5	6	7	8
Enable Falling	4909	4929	4949	4969	4989	5009	5029	5049
High Register for Counter	4910	4930	4950	4970	4990	5010	5030	5050
Low Register for Counter	4911	4931	4951	4971	4991	5011	5031	5051

Enable Full Scale. Set to 1 to enable a linear range from 0 to 65535 for specified input range. For a 4 to 20 mA input, a value of 0 represents 4 mA and 65535 represents 20 mA. Set this parameter to 0 to store input readings in unit-specific data. For example, the register data representing a 15.53 mA reading is 15530. For units of current (0 to 20 mA inputs), values are stored as μA (micro Amps) and voltage values are stored as mV (millivolts).

Enable Rising/Falling. Use these registers to enable the universal input logic to count on a rising transition or a falling transition. Write a one (1) to enable; write a zero (0) to disable.

High/Low Register for Counter. The low and high registers for the counter hold the 32-bit counter value. To erase the counter, write zeroes to both registers. To preset a counter value, write that value to the appropriate register.

Hysteresis and Threshold. Threshold and hysteresis work together to establish the ON and OFF points of an analog input. The threshold defines a trigger point or reporting threshold (ON point) for a sensor input. Setting a threshold establishes an ON point. Hysteresis defines how far below the threshold the analog input is required to be before the input is considered OFF. A typical hysteresis value is 10% to 20% of the unit's range.



In the example shown, the input is considered on at 15 mA. To consider the input off at 13 mA, set the hysteresis to 2 mA. The input will be considered off when the value is 2 mA less than the threshold.

Input Type. Program the universal inputs to accept input types NPN, PNP, 10k thermistor, 0 to 10 V, 0 to 20 mA, or potentiometer. The default setting is 8: NPN raw fast. To set the input type, write the following values to the Input Type Modbus registers.

- 0 = NPN
- 1 = PNP
- 2 = 0 to 20 mA
- 3 = 0 to 10 V dc
- 4 = 10k Thermistor
- 5 = Potentiometer Sense (DXM150 only)
- 6 = Not used
- 7 = Bridge
- 8 = NPN Raw Fast (default)

Temperature °C/°F. Set to 1 to represent temperature units in degrees Fahrenheit, and set to 0 (default) to represent temperature units in degrees Celsius.

Universal Input Register Ranges			
Register Types	Unit	Minimum Value	Maximum Value
Discrete input/output		0	1
Universal input 0 to 10 V	mV	0	10000 *
Universal input 0 to 20 mA	μA	0	20000 *
Universal input temperature (-40 °C to +85 °C)	C or F, signed, in tenths of a degree	-400	850
Universal potentiometer	unsigned	0	65535

* Setting Enable Full Scale to 1 sets the ranges to a linear scale of 0 to 65535.

4.6 Setting the Modbus Slave ID on the I/O Base Board

Only DXM150-Sx and SxR2 Modbus Slave models require that the Modbus Slave ID to be adjusted on the I/O base board. The DXM150-Sx Wireless Modbus Slave devices use DIP switch J and rotary dial K to set the Modbus slave ID. The device can use a Modbus register 6804 in the I/O board to access the full range of Modbus Slave IDs.

On the DXM150-Sx Wireless Modbus Slave models, use rotary dial K to select the lower digit of the Modbus Slave ID.

4.6.1 DXM150-Sx Wireless Modbus Slave Models

DIP Switch location J defines the course group of Modbus Slave IDs. DIP Switch 4 must be set to ON for DXM1xx-Sx and DXM1xx-SxR2 models.

Settings	Location J DIP Switches			
	1	2	3	4
Modbus Slave ID set to 11 through 19	OFF	OFF		
Modbus Slave ID set to 20 through 29	ON	OFF		
Modbus Slave ID set to 30 through 39	OFF	ON		
Modbus Slave ID set to 40 through 49	ON	ON		
Not Used			-	
Modbus Slave Configuration (S1 model only) ²				ON
I2C Processor Communication				OFF

Rotary dial location K and DIP Switch location J set the Modbus Slave IDs.

DIP Switches J		Location K Rotary Dials — Position 0 through 9									
1	2	0	1	2	3	4	5	6	7	8	9
OFF	OFF	x ³	11	12	13	14	15	16	17	18	19
ON	OFF	20	21	22	23	24	25	26	27	28	29
OFF	ON	30	31	32	33	34	35	36	37	38	39
ON	ON	40	41	42	43	44	45	46	47	48	49

DXM150-Sx Wireless Modbus Slave Example

To set the DXM150-Sx Wireless Modbus Slave to a Modbus Slave ID of 25, set the following:

Location J DIP switches set to: 1= ON, 2=OFF

Rotary dial set to 5

The DIP switch sets the upper digit of the slave ID to 2 while the rotary dial sets the lower digit to 5.

4.6.2 Setting the DXM I/O Board Modbus Slave ID using Modbus Registers

Write to the I/O board's Modbus register 6804 to set the Modbus Slave ID to any valid Modbus Slave ID (1 through 245).

- For the DXM150-Sx Wireless Modbus Slave model, rotary dial K should be in the zero position to use the Modbus register slave ID.

4.6.3 I/O Board Jumpers

Hardware jumpers on the DXM I/O board allow the user to select alternative pin operations. Turn the power off to the device before you change jumper positions.

² Must be in the ON position for the -S1 model)

³ Uses value in Modbus register 6804.

Jumper	Function	Positions
E	Courtesy power output	<p>Jumper 2 is the power jumper for pin 45. Jumper 1 is the power jumper for pin 35.</p> <ul style="list-style-type: none"> The pin 45 jumper selects 2.7 V when in the "a" position and 12 V battery in the "b" position. The pin 35 jumper selects 4.2 V when in the "a" position and device power on pin 2 in the "b" position.
G1	Not Used	Not Used
G2	Not Used	Not Used
G3	Analog output characteristics for AO2 (pin 32) and AO1 (pin 33)	<p>Defines current (0–20 mA) or voltage (0–10 V) for analog output 1 and 2.</p> <p>By default, current (0–20 mA) is selected using jumpers 1 and 2 and registers 4008 and 4028 contain a value of 2.</p> <p>To select voltage (0–10 V) for output Aout1, set jumper 1 in the voltage position (V) and set Modbus register 4008 on the I/O board to 3.</p> <p>To select voltage (0–10 V) for output Aout2, set jumper 2 in the voltage position (V) and set Modbus register 4028 on the I/O board to 3.</p>

5 I/O Base Board for the DXM150-S2 Models

5.1 Board Connections




Figure 5. Board Connections

***** THIS IS THE TABLE FOR THE DXM150-B2. PLEASE MARK THIS UP FOR THE DXM150-S2. *****

1	NC	17	Input 2B	33	Analog Output 1 (0–20 mA or 0–10 V)
2	12 to 30 V dc or solar power in (+)	18	Ground	34	Ground
3	Ground	19	Output 1 PNP/NPN	35	PWR Out - Jumper
4	Battery in (< 15 V dc) (must be a sealed lead acid battery)	20	Output 2 PNP/NPN	36	Ground
5	Ground	21	Output 3 PNP/NPN	37	Universal Input 8
6	Primary RS-485 –	22	Output 4 PNP/NPN	38	Universal Input 7
7	Primary RS-485 +	23	PWR Out OR	39	Universal Input 6
8	Ground	24	Ground	40	Universal Input 5
9	RS-232 Tx / CAN	25	Ground	41	Ground
10	RS-232 Rx / CAN	26	PWR OUT OR	42	Universal Input 4
11	Secondary RS-485 – or RS-232 RXRDY	27	Output 8 PNP/NPN	43	Universal Input 3
12	Secondary RS-485 + or RS-232 TXRDY	28	Output 7 PNP/NPN	44	Ground
13	Ground	29	Output 6 PNP/NPN	45	PWR Out - Jumper
14	Input 1A	30	Output 5 PNP/NPN	46	Universal Input 2
15	Input 1B	31	Ground	47	Universal Input 1
16	Input 2A	32	Analog Output 2 (0–20 mA or 0–10 V)	48	Ground

A	Base Board LED	E	PWR Out Jumpers	G3	Analog Output Characteristics Jumpers (Jumper 1 sets analog out 1, jumper 2 sets analog out 2)
---	----------------	---	-----------------	----	--

B	Cellular Antenna	F	Radio Binding Button	H	ISM Radio Connection
C	Radio LED	G1	RS-485 Jumpers	J	Modbus Slave ID DIP Switches
D	Radio Module Antenna	G2	RS-232 Jumpers	K	Rotary Dials
				L	SAM4 Processor Board Connection

5.1.1 DIP Switches for the I/O Board

The DXM150-Sx Wireless Modbus Slave I/O board DIP switches are set from the factory to Modbus Slave ID 11. For more information, refer to *Setting the Modbus Slave ID on the I/O Base Board*.

5.1.2 I/O Board Jumpers

Hardware jumpers on the DXM I/O board allow the user to select alternative pin operations. Turn the power off to the device before changing jumper positions.

Jumper	Function	Positions
E	Courtesy power output	Jumper 2 is the power jumper for pin 45. Jumper 1 is the power jumper for pin 35. <ul style="list-style-type: none"> The pin 45 jumper selects 2.7 V when in the "a" position and 12 V battery in the "b" position. The pin 35 jumper selects 4.2 V when in the "a" position and device power on pin 2 in the "b" position.
G1	RS-485 Modbus Slave or RS-232 Flow Control	Defines the operation of pins 11 and 12. Set the jumpers to use pins 11 and 12 as a secondary Modbus RS-485 slave port or flow control pins for the RS-232 port. Both jumpers must be set to the same operation, RS-485 Modbus Slave or Flow control. The default setting is RS-485.
G2	Generic RS-232 Serial Port or CAN Serial Port	Defines the operation of pins 9 and 10. Set the jumpers to use pins 9 and 10 as a CAN serial port or a generic RS-232 serial port. Both jumpers must be set to the same operation, CAN or RS232. The default setting is CAN serial port.
G3	Analog output characteristics for AO2 (pin 32) and AO1 (pin 33)	Defines current (0–20 mA) or voltage (0–10 V) for analog output 1 and 2. By default, current (0–20 mA) is selected using jumpers 1 and 2 and registers 4008 and 4028 contain a value of 2. To select voltage (0–10 V) for output Aout1, set jumper 1 in the voltage position (V) and set Modbus register 4008 on the I/O board (SID 200) to 3. To select voltage (0–10 V) for output Aout2, set jumper 2 in the voltage position (V) and set Modbus register 4028 on the I/O board (SID 200) to 3.

5.2 Applying Power

Apply power to the DXM Modbus Slave using either 12 to 30 V dc or a 12 V dc solar panel and 12 V sealed lead acid battery.

If the incoming voltage drops below 11.2 V dc, the cellular modem does not turn on and will not turn on until the voltage is above 11.8 V dc. A text file (CmVMon.txt) on the internal micro SD card saves the periodic sampling of the incoming voltage. If cellular operation stops because of voltage, it is logged in this file.

Pin	Description
Pin 1	No connection
Pin 2	12 to 30 V dc input (+) or solar panel connection (+)
Pins 3, 5, 8, 13, 18, 24, 25, 31, 34, 36, 41, 44, 48	Main logic ground for the DXM Modbus Slave
Pin 4	Solar or backup battery positive input. Battery voltage must be less than 15 V dc. Use only a sealed lead acid (SLA) battery.

Pin	Description
Pin 35, Pin 45	<p>These outputs are controlled by hardware jumpers.</p> <p>Jumper 2 is the power jumper for pin 45. Jumper 1 is the power jumper for pin 35. Refer to the wiring board for more information.</p> <ul style="list-style-type: none"> The pin 45 jumper selects 2.7 V when in the "a" position and 12 V battery in the "b" position. The pin 35 jumper selects 4.2 V when in the "a" position and device power on pin 2 in the "b" position.
Pin 23, Pin 26	Courtesy power output from either the input power from pin 2 or the battery power from pin 4.

5.2.1 Supplying Power from a Solar Panel

To power the DXM150-Sx Wireless Modbus Slave from a 12 V dc solar panel, connect the solar panel to power pins 2(+) and 3(-). Connect a 12 V dc sealed lead acid (SLA) rechargeable battery to pins 4(+) and 5(-).

The factory default setting for the battery charging algorithm assumes you are using 12 to 30 V dc power to recharge the battery. If the incoming power is from a solar panel, you must change the charging algorithm.

To change the charging algorithm from the menu system:

- From the DXM Modbus Slave LCD menu, navigate to **System Config > I/O Board > Charger**.
- Select **Solar** for solar panel configurations.

To change the charging algorithm by writing to Modbus register 6071 on the I/O base board (Slave ID 11):

- Write a 0 to select the solar power charging algorithm.

Modbus Slave ID	Modbus Register	Description
11 *	6071	<p>Battery backup charging algorithm.</p> <p>0 = Battery is recharged from a solar panel</p> <p>1 = Battery is recharged from 12 to 30 V dc (default)</p>

The following power operating characteristics are stored in Modbus registers.

Battery voltage

If no battery is present, the value in this register is less than 5 V. If the value in this register is greater than the incoming voltage register, the battery is powering the system.

Battery charging current

The charging algorithm charges the battery when the incoming voltage register value is greater than the battery voltage register value. This registers shows the charging current in milliamps.

Incoming supply voltage

The incoming power can be from a solar panel or from a power supply. The battery is charging when the incoming voltage register value is greater than the battery voltage register value. The battery is powering the system when the incoming voltage register value is less than the battery voltage register value.

On-board thermistor temperature

This register stores the on-board thermistor reading in tenths of degrees C, this is not a calibrated input: divide by 10 to calculate the temperature in degrees C. For calibrated temperature inputs, define one of the universal inputs as a temperature input.

Modbus Slave ID	Modbus Register	Description
11 *	6081	Battery voltage (mV)
	6082	Battery charging current (mA)
	6083	Incoming supply voltage (mV) (solar or power supply)
	6084	On-board thermistor temperature (°C)

* The Slave ID for the base board is set at the factory. This may be changed using the base board DIP switch settings.

5.2.2 Connecting a Battery to the DXM Modbus Slave

When attaching a battery to the DXM Modbus Slave as a backup battery or as a solar battery, verify the charging algorithm is set properly. The factory default setting for the battery charging algorithm assumes you are using 12 to 30 V dc to recharge the battery.

The charging algorithm is designed to work with a sealed lead acid (SLA) battery only.

- When using 12 to 30 V dc, connect the 12 to 30 V dc + to pin 2 and connect the ground to pin 3.
- When using main dc power with a back up battery (default configuration), connect the incoming main power pin 2 (+) and to pin 3 (-). Connect the 12 V sealed lead acid battery to pin 4 (+) and pin 5 (-). The incoming main power must be 15 to 30 V dc to charge the battery.
- When using a solar panel, connect the solar panel output to pin 2 and connect the ground to pin 3. Connect the 12 V dc SLA battery to pin 4 (+) and pin 5 (-). To change the charging algorithm, refer to [Supplying Power from a Solar Panel](#) on page 10.

The battery charging algorithm defaults to a battery backup configuration. To charge the battery from a solar panel, change the battery charging algorithm.

1. From the DXM Modbus Slave LCD menu navigate to **Setting Config > I/O Board > Charger**.
2. Select **Solar** for solar panel configurations or **DC** for battery backup configurations.

Modbus Slave ID	Modbus Register	Description
11 *	6071	Battery backup charging algorithm. 0 = Battery is recharged from a solar panel 1 = Battery is recharged from 12 to 30 V dc (default)

* The Modbus Slave ID for the base board is set at the factory and may be changed using the base board DIP switch settings.

5.3 Working with Solar Power

A reliable solar system requires careful planning and monitoring to size the components correctly. The recommendations provided are for the DXM Modbus Slave system as an autonomous system.

Adding extra components increases the power requirements and likely requires increasing the solar system components. Depending upon the geographical location, the size of the solar panel and battery may vary.

5.3.1 Setting the DXM Modbus Slave for Solar Power

By default, the DXM Modbus Slave is set from the factory to charge a backup battery from a line power source. Use the LCD menu on the front of the DXM Modbus Slave to change the charging algorithm to solar power.

Go to **System Config > I/O Board > Charger**. Use the up/down arrows to select **Solar**.

For DXM devices without an LCD, adjust the I/O board Modbus register 6071. Set the register to 0 to select battery charging from a solar panel, and set to 1 to select battery charging from incoming 12 to 30 V dc supply.

Here are a few DXM configuration tips to help minimize the power consumption (may not apply to all models).

- If Ethernet is not being used, save up to 25% of the consumed power by disabling Ethernet. Set DIP switch 1 to the ON position on the processor board then reboot.
- Instead of powering external devices all the time, take advantage of the switched power mechanisms to turn off devices when possible.
- Minimize the number of cellular transactions and the amount of data pushed across the cellular modem.

5.3.2 Solar Components

The components of a solar system include the battery and the solar panel.

Battery

The DXM solar controller is designed to use a 12 V lead acid battery. The characteristics of a solar system require the battery to be of a certain type. There are basically two types of lead acid batteries:

- SLI batteries (Starting Lights Ignition) designed for quick bursts of energy, like starting engines
- Deep Cycle batteries - greater long-term energy delivery. This is the best choice for a solar battery.

Since a solar system charges and discharges daily, a deep cycle battery is the best choice. There are different versions of a lead acid battery: wet cell (flooded), gel cell, and an AGM (absorbed glass mat).

Wet cell batteries are the original type of rechargeable battery and come in two styles, serviceable and maintenance free. Wet cell batteries typically require special attention to ventilation as well as periodic maintenance but are the lowest cost. The gel cell and AGM battery are sealed batteries that cost more but store very well and do not tend to sulfate or degrade as easily as a wet cell. Gel or AGM batteries are the safest lead acid batteries you can use.

Battery Capacity

Battery capacity is a function of the ambient temperature and the rate of discharge. Depending upon the specific battery, a battery operating at $-30\text{ }^{\circ}\text{C}$ can have as much as 40 percent less capacity than a battery operating at $20\text{ }^{\circ}\text{C}$. Choose enough battery capacity based on your geographical location.

A larger capacity battery typically lasts longer for a given solar application because lead-acid batteries do not like deep cycling (discharging a large percentage of its capacity). Depending upon the battery, a battery discharging only 30 percent of its capacity before recharging will have approximately 1100 charge/discharge cycles. The same battery discharging 50 percent of its capacity will have approximately 500 charge/discharge cycles. Discharging 100 percent leaves the battery with only 200 charge/discharge cycles.

Batteries degrade over time based on discharge/charge cycles and environmental conditions. Always monitor the battery system to obtain the best performance of the solar powered system.

Use this as a guide to the approximate state of charge and in determining when to apply conservation measures.

Average Voltage Readings Relative to Battery Change	
State of Charge (%)	Open Circuit Voltage
100	13.0 or higher
75	12.6
50	12.1
25	11.66
0	11.4 or less

Solar Panel

Banner solar panels come in two common sizes for the DXM Modbus Slave: 5 Watt and 20 Watt. Both panels are designed to work with the DXM Modbus Slave but provide different charging characteristics. Use the 5 watt panel for light duty operation and use the 20 watt panel when you require greater charging capabilities.

Solar Panel	Voltage	Current	Typical DXM Configurations
5 Watt	17 V	0.29 A	DXM slave controller, ISM radio, I/O base board
20 Watt	21 V	1 A	DXM Controller with ISM radio and Cellular modem

Photovoltaic panels are very sensitive to shading. Unlike solar thermal panels, PV solar panels cannot tolerate shading from a branch of a leafless tree or small amounts of snow in the corners of the panel. Because all cells are connected in a series string, the weakest cell will bring down the other cells' power level.

Good quality solar panels will not degrade much from year to year, typically less than 1 percent .

Solar Panel Mounting

To capture the maximum amount of solar radiation throughout the year, mount a fixed solar panel to optimize the sun's energy throughout the year. For the northern hemisphere, face the panel true south. For the southern hemisphere, face the panel true north. If you are using a compass to orientate the panels, compensate for the difference between true north and magnetic north. Magnetic declination varies across the globe.

A solar panel's average tilt from horizontal is at an angle equal to the latitude of the site location. For optimum performance, adjust the tilt by plus 15 degrees in the winter or minus 15 degrees in the summer. For a fixed panel with a consistent power requirement throughout the year, adjust the tilt angle to optimize for the winter months: latitude plus 15 degrees. Although in the summer months the angle may not be the most efficient, there are more hours of solar energy available.

For sites with snow in the winter months, the increased angle helps to shed snow. A solar panel covered in snow produces little or no power.

5.3.3 Recommended Solar Configurations

These solar panel and battery combinations assume direct sunlight for two to three hours a day. Solar insolation maps provide approximate sun energy for various locations. The depth of battery discharge is assumed to be 50 percent.

Solar panel and battery combinations for a DXM Modbus Slave system				
Solar Panel	Battery Capacity ⁴	Days of Autonomy	DXM mA	DXM Controller
5 watt	10 Ahr	10 days	25 mA	DXM Slave Controller - ISM radio and I/O base board
20 watt	14 Ahr	10 days	30 mA	DXM Controller with ISM radio
20 watt	20 Ahr	10 days	35 mA	DXM Controller with ISM radio and Cellular Modem

5.3.4 Monitoring Solar Operation

The DXM solar controller provides Modbus registers that allow the user to monitor the state of the solar panel input voltage, the battery voltage, the charging current, and the temperature in °C. The DXM Modbus Slave can be configured to monitor the health of the charging system as well as send an alert message when the battery is too low.

The charts show a typical charging cycle, with each vertical grid representing about eight hours. The chart shows three days of charging.




Figure 6. Solar Panel Voltage (mV) -- Cloudy First Day




Figure 7. Battery Voltage (mV) - Cloudy First Day

5.4 Connecting the Communication Pins

The base board communications connection for external Modbus device uses the primary RS-485.

RS-485. The primary RS-485 bus is a common bus shared with the ISM radio board (Modbus Slave ID 1).

RS-232. The RS-232 bus is not currently defined.

Pin	Parameter	Description
Pin 6	Primary RS-485 -	Running Modbus protocol at 19.2k baud, use this bus to connect to other Modbus Slave devices. The DXM150-Sx Wireless Modbus Slave is a Modbus Master device on this RS-485 port. Modbus Register 6101 = Baud Rate 0 = 19.2k 1 = 9600 2 = 38400 Modbus Register 6103 = Parity 0 = no parity 1 = odd? 2 = even?
Pin 7	Primary RS-485 +	

⁴ Battery capacity (amp hour) is standard amp rating taken for 20 hours. Battery capacity should be monitored for reliable system power and may need to be increased for cold weather locations.

Pin	Parameter	Description
Pin 9	RS-232 Tx	Serial RS-232 connection. This bus must use a ground connection between devices to operate correctly.
Pin 10	RS-232 Rx	
Pin 13	Secondary RS-485 -	Not used
Pin 14	Secondary RS-485 +	
Pin 15	CANL -	
Pin 16	CANH +	

5.5 Inputs and Outputs

The I/O base board is a Modbus slave device that communicates using Modbus commands. Refer to the Modbus Registers section for more descriptions of each Modbus register on the DXM150-Sx Wireless Modbus Slave.

5.5.1 Universal Inputs

The universal inputs can be programmed to accept different types of inputs: discrete NPN/PNP, 0 to 20 mA analog, 0 to 10 V analog, 10k thermistor, potentiometer sense, bridge, and NPN raw fast. Use the DXM Configuration Tool tool to write to the appropriate Modbus registers in the I/O board to configure the input type.

The universal inputs are treated as analog inputs. When the universal inputs are defined as mA, V, or temperature, use Modbus registers to configure the operational characteristics of the inputs. These parameters are temperature conversion type, enable full scale, threshold and hysteresis. See the Modbus register section for the parameter definitions.

When a universal input is configured as an NPN or PNP input type, it can be enabled to be a synchronous counter. Enable the counter function by setting Modbus register 'Enable Rising' or 'Enable Falling' to 1. See *Modbus Registers* for the universal input register definitions.

Pin	Univ. Input	Description
Pin 47	Universal Input 1	Program the universal inputs to accept input types NPN, PNP, 10k thermistor, 0 to 10 V, 0 to 20 mA, or potentiometer. The default setting is 8: NPN raw fast. To set the input type, write the following values to the Input Type Modbus registers. 0 = NPN 1 = PNP 2 = 0 to 20 mA 3 = 0 to 10 V dc 4 = 10k Thermistor 5 = Potentiometer Sense (DXM150 only) 6 = Not used 7 = Bridge 8 = NPN Raw Fast (default)
Pin 46	Universal Input 2	
Pin 43	Universal Input 3	
Pin 42	Universal Input 4	
Pin 40	Universal Input 5	
Pin 39	Universal Input 6	
Pin 38	Universal Input 7	
Pin 37	Universal Input 8	

Thermistor Input. A thermistor input must use a 10k thermistor between ground and the universal input. The thermistor must be a 10k NTC (Banner model number BWA-THERMISTOR-002) or equivalent. Select the temperature conversion of degrees C (default) or degrees F by writing to the Modbus registers defined in *I/O Base Board*.

Potentiometer Sense (DXM150 only). A potentiometer input is created from two inputs: a voltage source (pin 45) that supplies a voltage to the potentiometer and an input sense (Potentiometer Sense) to read the resistance. Follow [Example: Change Universal Input 8 to Read a Potentiometer Input](#) on page 18 to configure the DXM150 Controller for a potentiometer input.

Potentiometer Input (DXM100 only). A potentiometer input is created from three inputs: a voltage source (pin 30) that supplies 5 V to the potentiometer and two inputs set to voltage inputs to read the voltage across the potentiometer. See the DXM technical note for setting up a potentiometer.

Bridge Input. The bridge input is not implemented yet.

NPN vs NPN Raw Fast. The difference between NPN and NPN Raw Fast is the amount of settling time given to the input. Switch the input type to NPN if the input is not detecting a transition.

Example: Configure Input 1 as a Synchronous Counter

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. In the **Write Registers** area, write Modbus register 4908 to 1 to enable counting on the rising edge of the input signal.
8. Read Modbus registers 4910 and 4911 to get the 32-bit value of the count.

Example: Change Universal Input 2 to a 0 to 10 V dc Input

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. Write a 3 to Modbus register 3326 on Modbus Slave ID 11 (I/O board).
8. Cycle power to the device.
9. Using the **Register View** tab, read register 3326 to verify it is set to 3.

Example: Change Analog Output 1 to a 0 to 10 V dc Output

1. Connect the DXM Modbus Slave to the PC.
2. Launch the DXM Configuration Tool software.
3. Connect to the DXM Modbus Slave by selecting the **Device > Connection Settings** menu option. You may connect using either USB or Ethernet.
4. Select a COMM port from the drop-down list and click **Connect**.
5. Click on the **Register View** tab on the left part of the page.
6. Change the **Source Register** selection to **I/O Board Registers**.
7. Set jumper 1 on the I/O base board to the 0 to 10 V position. Refer to the base board image for the analog output jumper position.
8. Write a 3 to Modbus register 4008 on Modbus Slave ID 11 (I/O board).
9. Cycle power to the device.
10. Using the **Register View** tab, read register 4008 to verify it is set to 3.

Example: Change Universal Input 8 to Read a Potentiometer Input




Figure 8. Default jumper position

1. Launch the DXM Configuration Tool tool.
2. Click on the **Register View** tab on the left part of the page.
3. In the upper right part of the window select **Modbus Registers using Modbus Slave ID** radio button and enter Modbus Slave ID 11.
4. To set universal input 8 as the sense, write Modbus register 3446 with 5 (Potentiometer Sense).
5. Verify the jumpers are still set to their default position. One jumper should be on pins 1 and 3 to get a 2.7 V source voltage out pin 45. The default position of the other jumper is on pins 4 and 6.

- Connect one potentiometer side to power output (pin 45), connect the tap point of the pot to universal input 8 (pin 37), and connect the other end of the pot to ground (pin 36).

5.5.2 PNP and NPN Outputs

Pin	Output	Modbus Register	Description	PNP OUT Wiring	NPN OUT Wiring
19	1	501	PNP/NPN Output 1		
20	2	502	PNP/NPN Output 2		
21	3	503	PNP/NPN Output 3		
22	4	504	PNP/NPN Output 4		
30	5	505	PNP/NPN Output 5		
29	6	506	PNP/NPN Output 6		
28	7	507	PNP/NPN Output 7		
27	8	508	PNP/NPN Output 8		

5.5.3 Analog Outputs (DAC)

The following characteristics are configurable for each of the analog outputs.

Pin	Output	Description
Pin 33	Analog Output 1	0 to 20 mA or 0 to 10 V dc output (I/O board jumper selectable) Accuracy: 0.1% of full scale +0.01% per °C Resolution: 12-bit
Pin 32	Analog Output 2	

Parameters for Analog Output 1 start at 4001 through 4008. Parameters for Analog Output 2 start at 4021 through 4028.

Parameter Registers for Analog Outputs (4xxxx)		
OUT 1	OUT 2	Parameters
4001	4021	Maximum Analog Value
4002	4022	Minimum Analog Value
4003	4023	Enable Register Full Scale
4004	4024	Hold Last State Enable
4005	4025	Default Output State
4008	4028	Analog Output Type

Analog Output Type. The analog outputs may be configured as either 0 to 20 mA outputs (default) or 0 to 10 V outputs. To change the analog output type change the hardware jumper position and write to the Modbus register that defines the analog output type. For analog output 1, write to Modbus register 4008, for analog output 2 write to Modbus register 4028. Write a value of 2 (default) to select 0 to 20 mA; write a value of 3 to select 0 to 10 V.

Default Output Conditions. Default output conditions/triggers are the conditions that drive outputs to defined states. Example default output conditions include when radios are out of sync, when a device cycles power, or during a host communication timeout.

- 2952 Enable Default Communication Timeout.** A "communication timeout" refers to the communication between any Modbus master host and the DXM baseboard. Set this register to 1 to enable the default condition when the host has not communicated with the DXM baseboard for the period of time defined by the Communication Default IO Timeout.
- 2953 Communication Default I/O Timeout (100 ms/Count).** This parameter defines the host timeout period in 100 millisecond increments. If a host does not communicate within this timeout period, the device outputs are set to the default values.
- 2954 Enable Default on Power Up.** Setting this parameter to 1 sends the device outputs to their default condition when the DXM baseboard is powered up. Set to 0 to disable this feature.

Default Output State. The Default Output State parameter represents the default condition of the analog output. When an error condition exists, the outputs are set to this 16-bit user-defined output state. To define the error conditions for device outputs, refer to the MultiHop default output parameters 2950-2954.

Enable Register Full Scale. Set to 1 to enable a linear range from 0 to 65535 for specified input range. For a 4 to 20 mA output, a value of 0 represents 4 mA and 65535 represents 20 mA. Set this parameter to 0 to store readings in unit-specific data. For example, the register data representing a 15.53 mA reading is 15530. For units of current (0 to 20 mA outputs), values are stored as μ A (micro Amps) and voltage values are stored as mV (millivolts).

Hold Last State Enable. Set the Hold Last State to 1 to set the output to its last known value before the error occurred. Set this parameter to 0 to disable the Hold Last State and use the Default Output State setting during an error condition.

Maximum Analog Value. The Maximum Analog Value register stores the maximum allowed analog value. The specific units of measure apply to the register value. For example, the register may contain 20000, for 20 mA, or for a voltage output the register may contain 8000, for 8 volts.

Minimum Analog Value. The Minimum Analog Value register stores the minimum allowed analog value. The specific units of measure apply to register value. For example, the register may contain 4000, for 4 mA, or for a voltage output the register may contain 2000, for 2 volts.

5.5.4 Isolated Discrete Inputs

Pin	Input	Description	
Pin 14	Input 1A	Optically isolated AC input type, 0 to 12 to 30 V dc Input to output isolation of 2.5 kV	
Pin 15	Input 1B		
Pin 16	Input 2A		
Pin 17	Input 2B		

Synchronous Counters. An isolated input can be programmed to count the input signal transitions. When an input is enabled as a counter, the counter value is stored into two 16-bit Modbus registers for a total count of 32-bits (unsigned). To program an input to capture the edge transition counts, follow [Example: Configure Input 1 as a Synchronous Counter](#) on page 18.

The counters are synchronous because the inputs are sampled at a 10 ms clock rate. The input logic does not detect rising or falling edges, it samples the input every 10 ms to find level changes. The input signals must be high or low for more than 10 ms or the input will not detect transitions. Because most signals are not perfect, a realistic limit for the synchronous counter would be 30 to 40 Hz.

Universal inputs can also be configured as a synchronous counter. See the Modbus register map for universal inputs and all the register definitions. The procedure for creating a synchronous counter is the same as a isolated input with the addition of changing the input type to PNP or NPN.

Discrete Inputs	Modbus Registers for Counter Parameters	Register Definitions
Input 1	3013	Enable Rising
	3014	Enable Falling
	3015	Counter High
	3016	Counter Low
Input 2	3033	Enable Rising
	3034	Enable Falling
	3035	Counter High
	3036	Counter Low

5.5.5 Modbus Registers

The DXM MultiHop Modbus Slave device can have two Modbus Slave IDs: one for the MultiHop ISM radio (default 1) and one for the I/O base (default to 11). All Modbus registers are defined as 16-bit Modbus Holding Registers. When connecting additional Modbus slave devices, only use Modbus slave IDs 2 through 198.

Modbus Registers for the I/O Board

The I/O board is Slave ID 11.

Base Board Input Connection		Base Board Output Connection	
Modbus Register	Description	Modbus Register	Description
1	Optically isolated input 1	501	PNP/NPN Output 1
2	Optically isolated input 2	502	PNP/NPN Output 2
3	Universal input 1	503	PNP/NPN Output 3
4	Universal input 2	504	PNP/NPN Output 4
5	Universal input 3	505	PNP/NPN Output 5
6	Universal input 4	506	PNP/NPN Output 6
7	Universal input 5	507	PNP/NPN Output 7
8	Universal input 6	508	PNP/NPN Output 8
9	Universal input 7	509	DAC Output 1
10	Universal input 8	510	DAC Output 2

Configuration Registers for the I/O Board

The DXM Configuration Tool creates a graphical view of the I/O board parameters. This allows for easy and quick configuration of the I/O board parameters. Modbus configuration registers are identified below.

Register	Isolated Input A	Register	Isolated Input A
3013	Enable rising edge counter	3033	Enable rising edge counter
3014	Enable falling edge counter	3034	Enable falling edge counter
3015	High register for counter	3035	High register for counter
3016	Low register for counter	3036	Low register for counter


Universal Input Parameter Modbus Registers								
Universal Inputs	1	2	3	4	5	6	7	8
Enable Full Scale	3303	3323	3343	3363	3383	3403	3423	3443
Temperature °C/°F	3304	3324	3344	3364	3384	3404	3424	3444
Input Type	3306	3326	3346	3366	3386	3406	3426	3446
Threshold	3308	3328	3348	3368	3388	3408	3428	3448
Hysteresis	3309	3329	3349	3369	3389	3409	3429	3449
Enable Rising	4908	4928	4948	4968	4988	5008	5028	5048
Enable Falling	4909	4929	4949	4969	4989	5009	5029	5049
High Register for Counter	4910	4930	4950	4970	4990	5010	5030	5050
Low Register for Counter	4911	4931	4951	4971	4991	5011	5031	5051

Enable Full Scale. Set to 1 to enable a linear range from 0 to 65535 for specified input range. For a 4 to 20 mA input, a value of 0 represents 4 mA and 65535 represents 20 mA. Set this parameter to 0 to store input readings in unit-specific data. For example, the register data representing a 15.53 mA reading is 15530. For units of current (0 to 20 mA inputs), values are stored as μA (micro Amps) and voltage values are stored as mV (millivolts).

Enable Rising/Falling. Use these registers to enable the universal input logic to count on a rising transition or a falling transition. Write a one (1) to enable; write a zero (0) to disable.

High/Low Register for Counter. The low and high registers for the counter hold the 32-bit counter value. To erase the counter, write zeroes to both registers. To preset a counter value, write that value to the appropriate register.

Hysteresis and Threshold. Threshold and hysteresis work together to establish the ON and OFF points of an analog input. The threshold defines a trigger point or reporting threshold (ON point) for a sensor input. Setting a threshold establishes an ON point. Hysteresis defines how far below the threshold the analog input is required to be before the input is considered OFF. A typical hysteresis value is 10% to 20% of the unit's range.



In the example shown, the input is considered on at 15 mA. To consider the input off at 13 mA, set the hysteresis to 2 mA. The input will be considered off when the value is 2 mA less than the threshold.

Input Type. Program the universal inputs to accept input types NPN, PNP, 10k thermistor, 0 to 10 V, 0 to 20 mA, or potentiometer. The default setting is 8: NPN raw fast. To set the input type, write the following values to the Input Type Modbus registers.

- 0 = NPN
- 1 = PNP
- 2 = 0 to 20 mA
- 3 = 0 to 10 V dc
- 4 = 10k Thermistor
- 5 = Potentiometer Sense (DXM150 only)
- 6 = Not used
- 7 = Bridge
- 8 = NPN Raw Fast (default)

Temperature °C/°F. Set to 1 to represent temperature units in degrees Fahrenheit, and set to 0 (default) to represent temperature units in degrees Celsius.

Universal Input Register Ranges			
Register Types	Unit	Minimum Value	Maximum Value
Discrete input/output		0	1
Universal input 0 to 10 V	mV	0	10000 *
Universal input 0 to 20 mA	µA	0	20000 *
Universal input temperature (-40 °C to +85 °C)	C or F, signed, in tenths of a degree	-400	850
Universal potentiometer	unsigned	0	65535

* Setting Enable Full Scale to 1 sets the ranges to a linear scale of 0 to 65535.

Register	Description	Values	Register	Description
3704	Enable Discrete Output 1	0 = NPN; 1 = PNP	3705	Invert Output
3724	Enable Discrete Output 2	0 = NPN; 1 = PNP	3725	Invert Output
3744	Enable Discrete Output 3	0 = NPN; 1 = PNP	3745	Invert Output
3764	Enable Discrete Output 4	0 = NPN; 1 = PNP	3765	Invert Output
3784	Enable Discrete Output 5	0 = NPN; 1 = PNP	3785	Invert Output
3804	Enable Discrete Output 6	0 = NPN; 1 = PNP	3805	Invert Output
3824	Enable Discrete Output 7	0 = NPN; 1 = PNP	3825	Invert Output
3844	Enable Discrete Output 8	0 = NPN; 1 = PNP	3845	Invert Output

5.6 Setting the Modbus Slave ID on the I/O Base Board

Only DXM150-Sx and SxR2 Modbus Slave models require that the Modbus Slave ID be adjusted on the I/O base board. The DXM150-Sx Wireless Modbus Slave devices use DIP switch J and rotary dial K to set the Modbus slave ID. The device can use a Modbus register 6804 in the I/O board to access the full range of Modbus Slave IDs.

On the DXM150-Sx Wireless Modbus Slave models, use rotary dial K to select the lower digit of the Modbus Slave ID.

5.6.1 DXM150-Sx Wireless Modbus Slave Models

DIP Switch location J defines the course group of Modbus Slave IDs. DIP Switch 4 must be set to ON for DXM1.xx-Sx and DXM1.xx-SxR2 models.

Settings	Location J DIP Switches			
	1	2	3	4
Modbus Slave ID set to 11 through 19	OFF	OFF		
Modbus Slave ID set to 20 through 29	ON	OFF		
Modbus Slave ID set to 30 through 39	OFF	ON		
Modbus Slave ID set to 40 through 49	ON	ON		
Not Used			-	
Modbus Slave Configuration (S1 model only) ⁵				ON
I2C Processor Communication				OFF

Rotary dial location K and DIP Switch location J set the Modbus Slave IDs.

DIP Switches J		Location K Rotary Dials — Position 0 through 9									
1	2	0	1	2	3	4	5	6	7	8	9
OFF	OFF	x ⁶	11	12	13	14	15	16	17	18	19
ON	OFF	20	21	22	23	24	25	26	27	28	29
OFF	ON	30	31	32	33	34	35	36	37	38	39
ON	ON	40	41	42	43	44	45	46	47	48	49

DXM150-Sx Wireless Modbus Slave Example

To set the DXM150-Sx Wireless Modbus Slave to a Modbus Slave ID of 25, set the following:

Location J DIP switches set to: 1= ON, 2=OFF

Rotary dial set to 5

The DIP switch sets the upper digit of the slave ID to 2 while the rotary dial sets the lower digit to 5.

5.6.2 Setting the DXM I/O Board Modbus Slave ID using Modbus Registers

Write to the I/O board's Modbus register 6804 to set the Modbus Slave ID to any valid Modbus Slave ID (1 through 245).

- For the DXM150-Sx Wireless Modbus Slave model, rotary dial K should be in the zero position to use the Modbus register slave ID.

5.7 Restoring Factory Default Settings

To reset to factory defaults, write to two Modbus registers in the I/O board. The default slave ID for the I/O board is 11.

To reset the DXM I/O board parameters:

- Write a 1 to Modbus register 4152

⁵ Must be in the ON position for the -S1 model)

⁶ Uses value in Modbus register 6804.

2. Write a 10 to Modbus register 4151

To reset only the I/O board:

1. Write a 0 to Modbus register 4152
2. Write a 10 to Modbus register 4151

Modbus Register	Values	Description
4151	0-255	Reset/restore trigger. This timer is based in 100 millisecond units. Once written, the timer starts to count down to zero. After the timer expires, the restore factory defaults are applied if register 4152 = 1. If register 4152 is zero, the I/O board is reset. Default value: 0 1 = 100 milliseconds, 10 = 1 second.
4152	0-1	1 = Restores factory defaults for I/O parameters. Default value: 0

6 Restoring Factory Default Settings

To reset to factory defaults, write to two Modbus registers in the I/O board. The default slave ID for the I/O board is 11.

To reset the DXM I/O board parameters:





1. Write a 1 to Modbus register 4152
2. Write a 10 to Modbus register 4151

To reset only the I/O board:

1. Write a 0 to Modbus register 4152
2. Write a 10 to Modbus register 4151

Modbus Register	Values	Description
4151	0-255	Reset/restore trigger. This timer is based in 100 millisecond units. Once written, the timer starts to count down to zero. After the timer expires, the restore factory defaults are applied if register 4152 = 1. If register 4152 is zero, the I/O board is reset. Default value: 0 1 = 100 milliseconds, 10 = 1 second.
4152	0-1	1 = Restores factory defaults for I/O parameters. Default value: 0

7 DXM150 Dimensions



All measurements are listed in millimeters [inches], unless noted otherwise.

8 Accessories

For a complete list of all the accessories for the Sure Cross wireless product line, please download the [Accessories List](#) (p/n b_3147091)

Cordsets

MQDC1-506—5-pin M12/Euro-style, straight, single ended, 6 ft
 MQDC1-530—5-pin M12/Euro-style, straight, single ended, 30 ft
 MQDC1-506RA—5-pin M12/Euro-style, right-angle, single ended, 6 ft
 MQDC1-530RA—5-pin M12/Euro-style, right-angle, single ended, 30 ft

Static and Surge Suppressor

BWC-LFNBMN-DC—Surge Suppressor, bulkhead, N-Type, dc Blocking, N-Type Female, N-Type Male

Short-Range Omni Antennas

BWA-2O2-D—Antenna, Dome, 2.4 GHz, 2 dBi, RP-SMA Box Mount
 BWA-9O2-D—Antenna, Dome, 900 MHz, 2 dBi, RP-SMA Box Mount
 BWA-9O2-RA—Antenna, Rubber Fixed Right Angle, 900 MHz, 2 dBi, RP-SMA Male Connector

Medium-Range Omni Antennas

BWA-9O5-C—Antenna, Rubber Swivel, 900 MHz 5 dBi, RP-SMA Male Connector
 BWA-2O5-C—Antenna, Rubber Swivel, 2.4 GHz 5 dBi, RP-SMA Male Connector

Enclosures and DIN Rail Kits

[BWA-AH864](#)—Enclosure, Polycarbonate, with Opaque Cover, 8 × 6 × 4
[BWA-AH1084](#)—Enclosure, Polycarbonate, with Opaque Cover, 10 × 8 × 4
[BWA-AH12106](#)—Enclosure, Polycarbonate, with Opaque Cover, 12 × 10 × 6
 BWA-AH8DR—DIN Rail Kit, 8", 2 trilobular/self-threading screws
 BWA-AH10DR—DIN Rail Kit, 10", 2 trilobular/self-threading screws
 BWA-AH12DR—DIN Rail Kit, 12", 2 trilobular/self-threading screws

Misc Accessories

BWA-CG.5-3X5.6-10—Cable Gland Pack: 1/2-inch NPT, Cordgrip for 3 holes of 2.8 to 5.6 mm diam, qty 10
 BWA-HW-052— Cable Gland and Vent Plug Pack: includes 1/2-inch NPT gland, 1/2-inch NPT multi-cable gland, and 1/2-inch NPT vent plug, qty 1 each

Antenna Cables

BWC-1MRSMN05—LMR100 RP-SMA to N-Type Male, 0.5 m
 BWC-2MRSFRS6—LMR200, RP-SMA Male to RP-SMA Female, 6 m
 BWC-4MNFN6—LMR400 N-Type Male to N-Type Female, 6 m

Long-Range Omni Antennas

BWA-9O8-AS—Antenna, Fiberglass, 3/4 Wave, 900 MHz, 8 dBi, N-Type Female Connector
 BWA-2O8-A—Antenna, Fiberglass, 2.4 GHz, 8 dBi, N-Type Female Connector

Long-Range Yagi Antennas

BWA-9Y10-A—Antenna, 900 MHz, 10 dBd, N-Type Female Connector

Power Supplies

[PSD-24-4](#)—DC Power Supply, Desktop style, 3.9 A, 24 V dc, Class 2, 4-pin M12/Euro-style quick disconnect (QD)
[PSDINP-24-13](#)—DC Power Supply, 1.3 Amps, 24 V dc, with DIN Rail Mount, Class I Division 2 (Groups A, B, C, D) Rated
[PSDINP-24-25](#)—DC Power Supply, 2.5 Amps, 24 V dc, with DIN Rail Mount, Class I Division 2 (Groups A, B, C, D) Rated
[BWA-SOLAR PANEL 20W](#)—Solar Panel, 12 V, 20 W, Multicrystalline, 573 × 357 × 30, "L" style mounting bracket included (does not include controller)

9 Additional Information

9.1 DXM150 Documentation List

For more information about the DXM Modbus Slave family of products, please see additional documentation and videos on the Banner website: www.bannerengineering.com/wireless.

- DXM Wireless Controller Sell Sheet, p/n [194063](#)
- DXM150-B1 Wireless Controller Datasheet, p/n [178136](#)
- DXM150-B2 Wireless Controller Datasheet, p/n [195952](#)
- DXM150-Bx Wireless Controller Instruction Manual, p/n [190038](#)
- DXM150-S1 Modbus Slave Datasheet, p/n [160171](#)
- DXM150-S2 Modbus Slave Datasheet, p/n [200634](#)
- DXM150-Sx Modbus Slave Instruction Manual, p/n [195455](#)
- DXM ScriptBasic Instruction Manual, p/n [191745](#)
- DXM Controller Configuration Quick Start, p/n [191247](#)
- DXM Configuration Tool software (p/n [b_4447978](#))
- DXM Configuration Tool Instruction Manual, p/n [158447](#)
- DXM EDS [Configuration file](#) for Allen-Bradley PLCs
- EIP Configuration File for DXM 1xx-BxR1 and R3 models (p/n [194730](#))
- Activating a Cellular Modem (p/n [b_4419353](#))
- Additional technical notes and videos

Technical notes, configuration examples, and ScriptBasic program examples are available at <http://www.bannerengineering.com>.

9.2 DXM Modbus Slave Support Policy

The DXM Wireless Controllers are industrial wireless controllers that facilitate Industrial Internet of Things (IIoT) applications. As a communications gateway, it interfaces local serial ports, local I/O ports, and local ISM radio devices to the Internet using either a cellular connection or a wired Ethernet network connection. In a continuing effort to provide the best operation for the DXM Modbus Slave, stay connected with Banner Engineering Corp to hear about the latest updates through the Banner website. Create a login today to stay informed of all Banner product releases.

9.2.1 Firmware Updates

The DXM Modbus Slave has been designed to be a robust and secure IOT device. To provide the most reliable and secure device possible, periodic firmware updates are released to enhance and expand the capabilities of the DXM Modbus Slave. Firmware updates and description details are found on the Banner website. Customers with critical update requirements will get access to pre-released firmware from the factory.

9.2.2 Website Information

The Banner website is the main method of disseminating DXM Modbus Slave information to customers. The data found on the website include:

- DXM instruction manuals
- Configuration manuals
- Firmware downloads
- Firmware release notes
- Errata data, any known issues with a release of firmware
- Possible work-around solutions for known issues
- DXM Solutions Guides

9.2.3 Feature Requests

Our customer is our most valuable resource to improve our DXM Modbus Slave. If you have suggestions for improvements to the DXM Modbus Slave or configuration tools, please contact Banner Engineering Corp.

9.2.4 Potential DXM Issues

Potential issues with the DXM Modbus Slave are collected from Banner's support engineers to provide solutions. Users can get help from the website documentation or by calling Banner Engineering for support help. Solutions are as simple as configuration adjustments, work-around configuration solutions, or potential new firmware updates.

9.2.5 DXM Security

The DXM Modbus Slave was designed to collect local wireless sensor data, local sensor data, provide simple control, and send the data to the cloud.

The DXM Modbus Slave does not run a Linux or Windows based operating system but an embedded RTOS environment. As a proprietary operating system, the security aspects are easier to manage and minimize.

Security updates are released through the Banner website and New Product Release Announcements (NPRA).

9.3 Contact Us

Corporate Headquarters

Address:
Banner Engineering Corporate
9714 Tenth Avenue North
Minneapolis, Minnesota 55441, USA

Phone: +1 763 544 3164
Website: www.bannerengineering.com

Europe

Address:
Banner Engineering EMEA
Park Lane, Culliganlaan 2F, bus 3
1831 Diegem, Belgium

Phone: +32 (0)2 456 0780
Website: www.bannerengineering.com
Email: mail@bannerengineering.com

Turkey

Address:
Banner Engineering Elk. San. Ve Tic. Ltd. Şti.
Şerifali Mah. Münevver Sok. Ekomed Plaza No:10 Kat:4
Ümraniye / İstanbul, Türkiye

Phone: +90 216 688 8282
Website: www.bannerengineering.com
Email: turkey@bannerengineering.com.tr

India

Address:
Banner Engineering India Pune Head Quarters
Office No. 1001, 10th Floor Sai Capital, Opp. ICC Senapati Bapat Road
Pune 411016, India

Phone: +91 (0) 206 640 5624
Website: www.bannerengineering.com
Email: salesindia@bannerengineering.com

Mexico

Address:
Banner Engineering de Mexico Monterrey Head Office
Edificio VAO Av. David Alfaro Siqueiros No.103 Col. Valle Oriente C.P.66269
San Pedro Garza Garcia, Nuevo Leon, Mexico

Phone: +52 81 8363 2714 or 01 800 BANNERE (toll free)
Website: www.bannerengineering.com
Email: mexico@bannerengineering.com

Brazil

Address:
Banner do Brasil
Rua Barão de Teffé nº 1000, sala 54
Campos Elíseos, Jundiaí - SP, CEP.: 13208-761, Brasil

Phone: +55 11 2709 9880
Website: www.bannerengineering.com
Email: brasil@bannerengineering.com

China

Address:
Banner Engineering Shanghai Rep Office
Xinlian Scientific Research Building Level 12, Building 2
1535 Hongmei Road, Shanghai 200233, China

Phone: +86 212 422 6888
Website: www.bannerengineering.com
Email: sensors@bannerengineering.com.cn

Japan

Address:

Banner Engineering Japan
Cent-Urban Building 305 3-23-15 Nishi-Nakajima Yodogawa-Ku
Osaka 532-0011, Japan

Phone: +81 (0)6 6309 0411

Website: www.bannerengineering.com

Email: mail@bannerengineering.co.jp

Taiwan

Address:

Banner Engineering Taiwan
8F-2, No. 308 Section 1, Neihu Road
Taipei 114, Taiwan

Phone: +886 (0)2 8751 9966

Website: www.bannerengineering.com

Email: info@bannerengineering.com.tw

10 Warnings

Install and properly ground a qualified surge suppressor when installing a remote antenna system. Remote antenna configurations installed without surge suppressors invalidate the manufacturer's warranty. Keep the ground wire as short as possible and make all ground connections to a single-point ground system to ensure no ground loops are created. No surge suppressor can absorb all lightning strikes; do not touch the Sure Cross® device or any equipment connected to the Sure Cross device during a thunderstorm.

Exporting Sure Cross® Radios. It is our intent to fully comply with all national and regional regulations regarding radio frequency emissions. **Customers who want to re-export this product to a country other than that to which it was sold must ensure the device is approved in the destination country.** A list of approved countries appears in the *Radio Certifications* section of the product manual. The Sure Cross wireless products were certified for use in these countries using the antenna that ships with the product. When using other antennas, verify you are not exceeding the transmit power levels allowed by local governing agencies. Consult with Banner Engineering Corp. if the destination country is not on this list.

10.1 Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.