


# MINI-BEAM (Low Power Model)



## Datasheet



A self-contained dc-operated low-power sensor for use with the Sure Cross® devices



- Optimized for duty cycled battery-powered operation for the DX80 FlexPower® Nodes
- Compact, modulated, self-contained, low-power sensors for 5 V dc operation
- Available models include diffuse and extended-range polarized retroreflective
- Switch-selectable for light or dark operate

For additional information, updated documentation, and a list of accessories, refer to Banner Engineering's website, [www.bannerengineering.com/wireless](http://www.bannerengineering.com/wireless).

## Models

Model	Power	Range	Type
SM312LPQD-78447	5 V	3 m	 POLAR RETRO
SM312DQD-78419		38 cm	 DIFFUSE




### WARNING: Not To Be Used for Personnel Protection

Never use this device as a sensing device for personnel **protection**. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.


## Installation

### Wiring Diagrams



	Wire Color	Description
1	Brown	5 V dc
2	White	Load
3	Blue	Ground

### Sensor **Operation** with the DX80 FlexPower System



Efficient power management technology enables the FlexPower battery system to briefly step up the switched power voltage to activate the low-power MINI-BEAM® sensor, which is optimized for low duty cycle pulse operation. Once activated, the input reads the sensor then the switched power shuts off to prolong battery life, operating the MINI-BEAM in short pulses rather than continuously.

## Sensor **M**ounting and Alignment

MINI-BEAM sensors perform most reliably when they are properly aligned and securely mounted. For maximum mechanical stability, mount MINI-BEAM sensors through 18 mm diameter holes by their threaded barrel where available or use a mounting bracket.

Begin with line-of-sight positioning of the MINI-BEAM sensor to its target. When using a retroreflective sensor, the target is the retroreflector (retro target). For diffuse or convergent sensing modes, the target is the object to be detected.

Apply power to the sensor. Advance the 15-turn gain control to maximum (clockwise end of rotation), using a small flat-bladed screwdriver. The gain control is clutched at both ends to avoid damage and “free-wheels” when either endpoint is reached. Because the low-power MINI-BEAM operates in pulses instead of continuously, sensor alignment is more complicated. To simplify alignment, force the sensor to mimic continuous operation by hooking up the sensor to a fixed 5.0 voltage supply or by configuring the warm-up time to its maximum allowable value. After establishing the optimum position, configure the warm-up time back to the value listed in the specifications table.

When the MINI-BEAM sensor receives its light signal, the red LED alignment indicator turns ON and flashes at a rate proportional to the signal strength. Move the sensor to find the center of the movement zone within which the LED indicator remains ON. Reducing the gain setting reduces the size of the movement zone and permits more precise alignment.

Repeat the alignment motions after each gain reduction. When optimum alignment is achieved, mount the sensor and any applicable target (retroreflective) in that position. Increase the gain to maximum.

Test the sensor by placing the object to be detected in the sensing position, then removing it. The alignment indicator LED should come ON when the sensing beam is established (light condition), and go OFF when the beam is broken (dark condition). If the alignment indicator LED stays ON for both sensing conditions, consider the following tips for each sensing mode.


### Diffuse-Mode Alignment

Light condition: object in beam

Dark condition: no object in beam

If the alignment LED does not go off when the object is removed from the beam, the sensor is probably detecting light reflected from a background object. To improve performance:

- Reduce the reflectivity of the background by painting the surface flat black, scuffing any shiny surface, or drilling a large hole directly opposite the diffuse sensor.
- Move the sensor closer to the object to be detected and reduce the gain adjustment. Rule of thumb for diffuse sensing: the distance to the nearest background object should be at least three times the sensing distance.




### Retroreflective Mode Alignment

Light condition: no object in beam

Dark condition: object in beam

A highly reflective object may reflect enough light back to a retroreflective sensor to allow the object to cross the beam without being detected, a situation called proxing. Use the following methods to reduce this effect:

- Position the sensor and retro target until the beam does not strike a shiny surface perpendicular to the sensor lens.
- Reduce the gain adjustment.



## Discrete **C**onfiguration

The battery life calculations, in years, for some discrete sensors are shown in the table below.

Table 1: Battery Life in Years


	Manufacturer	Device	Model	Boost Voltage	Warmup Time
1	Banner	Optical	SM312DQD-78419	5 V	4 ms

	Manufacturer	Device	Model	Boost Voltage	Warmup Time
2	Turck	Inductive Proximity	Bi10U-M30-AP6X-H1141	10 V	10 ms

	Sample and Report Rates						
	62.5 ms	125 ms	250 ms	500 ms	1 second	2 seconds	16 seconds
1	0.97	1.67	2.62	3.74	4.75	5.49	6.28
2	0.20	0.40	0.72	1.27	2.05	2.99	5.07

Note, battery life calculations are based on the sensor operating 24 hours a day, 365 days a year.



For each sensor characterized, a boost voltage and warmup time was specified. The sample and reports rates were varied to calculate the estimated battery life. For example, a Banner Optical sensor, model SM312DQD-78419, set to a boost voltage of 5 volts, a warm-up time of 4 milliseconds, and a sample and report rate of 16 seconds, should have a battery life of just over 6 years.

The curves for discrete devices represent a “worst case” as far as battery use because we are assuming for each sample of the sensor’s output a change in state has occurred (e.g., target present to target absent or vice versa), sending a radio message from Node to Gateway. No messaging occurs unless there is a change to report. Actual battery life depends on how many state changes actually occur.

All battery life calculations are approximations based on a strong radio signal. Weaker radio connections and missed packets will decrease the battery life.

## Low-Power MINI-BEAM Specifications

Supply Voltage  
5 V dc

Supply Current  
Depends on the pulse duty cycle system of the *FlexPower*® device. For example, at 5 Volts and a 62.5 millisecond sample rate, the maximum sensor current is 1.1 mA.

Warm-up Time  
4 milliseconds

Output **Configuration**  
One current sinking (NPN) open collector transistor

### Adjustments

LIGHT/DARK OPERATE select switch, and 15-turn slotted brass screw GAIN (sensitivity) adjustment potentiometer (clutched at both ends of travel). Both controls are located on the rear panel of the sensor and protected by a gasketed, clear acrylic cover.

### Indicators

Alignment Indicating Device system (AID) lights a rear-panel mounted red LED indicator when the sensor sees a “light” condition, with a superimposed pulse rate proportional to the light signal strength (the stronger the signal, the faster the pulse rate).

### Construction

Reinforced thermoplastic polyester housing, totally encapsulated, o-ring sealing, acrylic lenses, and stainless steel screws.

**Environmental Rating**  
NEMA standards 1, 2, 3, 3S, 4, 4X, 6, 12, and 13; IEC IP67

**Operating Conditions**  
Temperature: -20 to +70° C  
Humidity: 90% max. relative (non-condensing) at 50° C

**Certifications**



**Required Overcurrent Protection**




**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.  
Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.  
Supply wiring leads < 24 AWG shall not be spliced.  
For additional product support, go to [www.bannerengineering.com](http://www.bannerengineering.com).

Supply Wiring (AWG)	Required Overcurrent Protection (Amps)
20	5.0
22	3.0
24	2.0
26	1.0
28	0.8
30	0.5

**Dimensions**



**Warnings**

**Violating Warnings.** The manufacturer does not take responsibility for the violation of any warning listed in this document. Make no **modifications** to this product; any modifications to this product not expressly approved by Banner Engineering could void the user's authority to operate the product. All **specifications** published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com). © Banner Engineering Corp. All rights reserved.

**Banner Engineering Corp. Limited Warranty**

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com).