

Product Features

Miniature sensors featuring extended range and electronically adjustable background suppression mode



- Miniature sensor for installation in the smallest of spaces
- Exceptional optical performance; up to 400 mm sensing range in miniature QS18 housing
- Background suppression models for reliable detection of objects when the background condition is not controlled or fixed
- Simple TEACH adjustment of cutoff distance
- Enhanced immunity to fluorescent lights
- Class 1 IR Laser emitter

WARNING:



- Do not use this device for personnel protection
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.


Models

Models	Sensing Beam	Range	Connection ¹	Supply Voltage	Output Type
QS18N6LAF400IR	940 nm Infrared Laser	20-400 mm (1.2 in-15.7 in)	2 m (6.5 ft) 3-wire	10 to 30 V dc	NPN LO/DO
QS18P6LAF400IR					PNP LO/DO
QS18RN6LAF400IR					NPN DO
QS18RP6LAF400IR					PNP DO
QS18AN6LAF400IR					NPN LO
QS18AP6LAF400IR					PNP LO

¹ Only standard 2 m (6.5 ft) cable models are listed.

- For 4-pin M8 pigtail QD: add suffix "Q" to the model number (for example, QS18NLAF400IRQ);
- For 3-pin M8 pigtail QD: add suffix "Q3" to the model number (for example, QS18NLAF400IRQ3);
- For 4-pin M12: add suffix "Q4" to the model number (for example, QS18NLAF400IRQ4);
- For 4-pin M12 pigtail QD: add suffix "Q5" to the model number (for example, QS18NLAF400IRQ5);
- For 4-pin integral QD: add suffix "Q7" to the model number (for example, QS18NLAF400IRQ7);
- For 4 or 5 pin Euro QD: add suffix "Q8" to the model number (for example, QS18NLAF400IRQ8);

Overview



The QS18LAF400IR Laser Measurement Sensor ignores objects beyond the set cutoff distance. Background suppression mode can be used in most situations with varying object color and position or with varying background conditions.

1. Green: Power Indicator
2. Amber: Output Indicator

QS18LAF400IR Laser Description and Safety Information

CAUTION:



- Return defective units to the manufacturer.
- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- Do not attempt to disassemble this sensor for repair. A defective unit must be returned to the manufacturer.

Class 1 lasers are lasers that are safe under reasonably foreseeable conditions of operation, including the use of optical instruments for intrabeam viewing.

Laser Classification

Class 1 laser product; Complies with IEC 60825-1:2014 and 21 CFR 1040.10, except for deviations pursuant to Laser Notice 56, dated 5-08-19



Laser Wavelength

940 nm

Average Output Power

0.9 mW

Pulse Width

3 ms

Rep Rate

30 - 90 ms

Installation


Mount the Device

1. If a bracket is needed, mount the device onto the bracket.
2. Mount the device (or the device and the bracket) to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.
3. Check the device alignment.
4. Tighten the mounting screws to secure the device (or the device and the bracket) in the aligned position.


QS18LAF400IR Wiring

CAUTION: Cabled wiring diagrams are shown. Quick disconnect wiring diagrams are functionally identical. Observe proper ESD precautions (grounding) when connecting quick disconnect models.

NPN (Sinking) Outputs



PNP (Sourcing) Outputs



Wiring Key

- 1 = Brown
- 3 = Blue
- 4 = Black

Configuration Instructions

Select the TEACH Mode

A. Single point mode

1. Move target to a position (less than 400mm).
2. Press and hold the button for 2-4 seconds until green LED is on and yellow LED flash
3. Press the button once to complete single point mode teach
4. If teaching fails, green and yellow LED will flash five times together.

B. Background mode

1. Move target to a position (less than 400mm).
2. Press and hold the button for 4-6 seconds until yellow LED is on and green LED flash
3. Press the button once to complete single point mode teach
4. If teaching fails, green and yellow LED will flash five times together.

C. Two-point Window

1. Move target to first point.
2. Press and hold the button for 6-8 seconds until green LED and yellow LED flash alternately
3. Press the button once to teach first point
4. Then yellow LED is off and green LED flash
5. Move white card to second point.
6. Press the button once to teach second point and complete two point mode teach
7. If teaching fails, green and yellow LED will flash five times together.

D. Change output mode

1. Press and hold the button for 8-10 seconds until green LED and yellow LED are on together
2. Release the button to change to NO or NC

E. Cancel teach

1. Press and hold the button more than 10 seconds to cancel teach mode.

QS18LAF400IR Specifications

Supply Voltage

10 V DC to 30 V DC (10% maximum ripple within specified limits) at less than 15 mA, exclusive of load

Supply Protection Circuitry

Protected against reverse polarity and transient voltages

Output Configuration

Solid-state complementary (SPDT): NPN or PNP (current sinking or sourcing), depending on model;

Off-state leakage current: less than 5 μ A at 30 V dc

ON-state saturation voltage:

NPN: less than 1.5 V;
PNP: less than 2.0 V

Output Rating

100 mA total output current

Sensing Beam

Infrared laser, 940 nm

Connections

2 m (6.5 ft) unterminated 3-wire PVC-jacketed cable, 150 mm (6 in) PVC-jacketed cable with a 4-pin M8 male quick-disconnect connector, or 150 mm (6 in) PVC-jacketed cable with a 4-pin M12 male quick-disconnect connector, depending on the model.

Ambient Light Immunity

25K lux

Adjustments

One TEACH button

Environmental Rating

IP67

Operating Conditions

-10 °C to +50 °C (14 °F to +122 °F)

95% at +50 °C maximum relative humidity (non-condensing)

Certifications



Response Speed

less than 30 milliseconds ON/OFF

Indicators

Two LED indicators on the sensor top:

Green on: Power is on

Amber on: Output is on

Construction

PC/ABS housing, acrylic lens cover; PVC cable

Spot Size

QS18LAF400IR	
Distance (mm)	Size (Horizontal x Vertical) (mm)
30	12 x 15
100	35 x 45
200	70 x 85
300	100 x 125
400	140 x 170

Required Overcurrent Protection



WARNING: Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.


Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (A)	Supply Wiring (AWG)	Required Overcurrent Protection (A)
20	5.0	26	1.0
22	3.0	28	0.8
24	2.0	30	0.5


QS18LAF400IR Performance Curves




X: Distance to Object (mm)

Y: Minimum Separation Between Object and Background (mm)

QS18 Minimum Separation Object to Background




QS18 TOF Beam Pattern



Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.



Hardware Included:

- Two M3 x 0.5 - 6g x 20 mm SS Screws
- Two M3 x 0.5 - 6H SS Nuts
- Two M3 flat SS Washers

Maximum torque 0.9 Nm (8 in-lbf)

Accessories

Cordsets

4-Pin Threaded M8 Cordsets—Single Ended				
Model	Length	Style	Dimensions	Pinout (Female)
PKG4M-2	2.04 m (6.68 ft)	Straight		
PKG4M-5	5 m (16.4 ft)			
PKG4M-9	9.04 m (29.6 ft)			
PKW4M-2	2 m (6.56 ft)	Right Angle		
PKW4M-5	5 m (16.4 ft)			
PKW4M-9	9 m (29.5 ft)			

1 = Brown
 2 = White
 3 = Blue
 4 = Black

4-Pin Threaded M12 Cordsets—Single Ended				
Model	Length	Style	Dimensions	Pinout (Female)
MQDC-406	2 m (6.56 ft)	Straight		
MQDC-415	5 m (16.4 ft)			
MQDC-430	9 m (29.5 ft)			
MQDC-450	15 m (49.2 ft)	Right-Angle		
MQDC-406RA	2 m (6.56 ft)			
MQDC-415RA	5 m (16.4 ft)			
MQDC-430RA	9 m (29.5 ft)			
MQDC-450RA	15 m (49.2 ft)			


1 = Brown
 2 = White
 3 = Blue
 4 = Black
 5 = Unused

Brackets

All measurements are listed in millimeters, unless noted otherwise.

SMBQS18A

- Wrap-around protection bracket
- Die-cast bracket
- Base fits 18 mm threaded hole
- Metal hex nut, lock washer and grommet included
- Mounting holes specially designed for QS18AF sensors




Hole size: A = \varnothing 15.3

SMBQS18AF

- Right-angle mounting bracket
- 14-ga. 304 stainless steel

Hole center spacing: A to B = 20.3

Hole size: A = 4.3 \times 9.4, B = \varnothing 4.3



Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

Document title: QS18 Infrared Electronically Adjustable Time of Flight Background Suppression Sensor

Part number: 238145

Revision: B

Original Instructions

© Banner Engineering Corp. All rights reserved.



238145