

IOLM v16 Update

6/21/2021


This document covers the installation and use of the IOLM function for Siemens's TIA Portal software package. This function handles the passing of Parameter data information from an IO-Link Master back to the Siemens PLC. These instructions show how to use the updated IOLM function block for TIA Portal V16.

Components


Banner IOLM v16.zal16

Installation Instructions


1. Open a project.
2. Go to Libraries tab. Use the "Open Global Library" icon.



3. Switch the "Files of type" from "Global library" to "Compressed libraries". This allows an archived library to be opened.



- Navigate to the location that the archived library is at. Select the library and press the Open button.



- Window will open requiring the user to “Select Target Directory” for the library to be stored in. The library Banner IOLM v16 will now be saved into that folder.
- The Banner IOLM v16 Library will now be in the Global Library List. Expand the Master copies section. The folder contains these items: Banner_IOLM, Banner_IOLM_Control, and Banner_IOLM_EL.
- Drag Banner_IOLM_Control to the Program Blocks area under your PLC.
- Drag the other items listed above to the PLC Data Types area under your PLC.
- Siemens function block LIOLINK_Device v6.0 is required for the above function block to work. This can be download on the Siemens website.
- The LIOLINK Device v6.0 needs to in project. If not pull it into the project.
- Installation of Banner IOLM v16 is complete.

