


Replace the DX99D Battery Board




Replace the DX99D Battery Board

The replacement kit includes the following parts:


- Battery board and ribbon cable
- Plastic ring



1. Remove top cover from metal enclosure.
2. Disconnect the ribbon cable from the radio board.
3. Using a 3 mm Allen/hex key wrench, remove the four screws mounting the battery board to the base of the enclosure.



4. Replace the battery board assembly with the new assembly.
5. Fasten down with the four screws.
6. Insert the supplied plastic ring into the enclosure top piece and push it down against the metal ring until it fits tightly.



7. Screw down the enclosure top cover and hand tighten.