Using the User Configuration Tool (UCT) with Microsoft Windows® 7

Some computer systems running Microsoft Windows 7 may not run the User Configuration Tool if the user is not configured with administrator rights on the computer system.

To allow the User Configuration Tool to run on Windows 7, follow these steps:

1. Right-click on the UCT icon.
2. Go to Properties.
3. Select the Compatibility tab.
4. Select the "Run this program as an administrator" checkbox.
5. Click on the OK button to accept the change.