

Safety Controller PC Interface Release Notes



Release Notes

This document contains information on current and past releases of the Safety Controller PC Interface software.

Version 4.1.0

May 2019

SC10 Safety Controller

Added the following language options German, Spanish, French, Italian, Japanese, Korean, Portuguese, Chinese (Mainland), Chinese (Taiwan).

SC26 and XS26 Series Safety Controllers

No new features have been added since Version 3.3.0

Version 4.0.0

April 2019

SC10 Safety Controller

Initial launch of the SC10 product. Supports all features and functions as detailed in the Instruction Manual.

SC26 and XS26 Series Safety Controllers

No new features have been added since Version 3.3.0

Version 3.3.0

May 2018

SC10 Safety Controller

Not Applicable

SC26 and XS26 Series Safety Controllers

New Features

- Added delay state indication to function blocks and safety outputs in Live Mode.
- Added ability to toggle an input reference node in Simulation Mode.
- Added status output states in Functional View in Simulation Mode.
- Added milliseconds option to Muting Time Limit feature.

Version 3.2.0 and earlier

For details on these versions, choose the Help button  on the toolbar of the PC Interface software. Then select the Release Notes option.