

Datasheet

IEC Class 1 Laser for Use with Banner Modulated Receivers



- A low-power device emitting a visible red beam, 650 nm wavelength
- Beam is bore-sighted to within 2 milliradians and 0.25 mm of the housing centerline
- Collimated, apertured beam is 2 mm diameter with divergence of less than 1 milliradian
- Compatible with a variety of Banner modulated photoelectric receivers
- Useful for medium-range sensing, or for sensing very small objects or profiles; excellent mechanical repeatability in position-sensing applications
- Smooth-barrel aluminum housing is suitable for a precision mount
- Available with unterminated, 2 m (6.5 ft) cable or 150 mm (6 in) quick-disconnect cable
- Modulated beam (33 kHz, 25% duty cycle)
- 57 mm (2.25 in) long overall
- 10 V dc to 30 V dc operation



WARNING: Not To Be Used for Personnel Protection

Never use this device as a sensing device for personnel **protection**. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.



CAUTION: Never stare directly into the sensor lens. Laser light can damage your eyes. Avoid placing any mirror-like object in the beam. Never use a mirror as a retroreflective target.



CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Do not attempt to disassemble this sensor for repair. A defective unit must be returned to the manufacturer.

Models

Model	Range	Connector ¹	Supply Voltage	Effective Beam at Receiver at 25° C	
		2 (/ 5 6)		Opposed Distance	Beam Width
M126E1LD	2 m (6.5 ft) unterminated		1.5 m (5 ft)	3.5 mm (0.14 in)	
	Range varies, depending on which receiver is used (see <i>Excess Gain</i> on page 4)		10 V dc to 30 V dc	3 m (10 ft)	5 mm (0.2 in)
		150 mm (6 in) PVC cable with 3-wire Pico-style quick disconnect		6 m (20 ft)	8 mm (0.3 in)
				15 m (50 ft)	17 mm (0.7 in)
				30 m (100 ft)	32 mm (1.3 in)

Installation

Mounting

Mounting suggestions:

- To take advantage of the bore-sight beam placement offered by the M12 laser emitter, use a two-part clamp mount or a mounting block with a precision-drilled hole. Allow minimum clearance for the 12.7 mm (0.50 in) diameter housing, maximum diameter 12.83 mm (0.505 in).
- Clamp on both sides of the label. Do not clamp only on the labeled area. Use only plastic-tipped screws or set screws not metal to avoid compression of the housing.

Mounting bracket assembly model SMB46X3 is recommended for use with the M12. The assembly includes:

To order the 9 m (30 ft) PVC cable model, replace the suffix "Q" with "W/30" in the model number. For example, M126E1LDQ W/30. Models with a quick disconnect require a mating cordset.



Original Document 53808 Rev. C

- A black-anodized aluminum block with holes drilled for mounting in any of 3 directions with plastic set screws
- An adjustable stainless steel bracket with 3 spring-loaded screws (2 of the screws are used for precise alignment)

The mounting block, model SMB127, can be ordered separately.




Figure 1. Three Possible M12 Orientations

- 1. Insert the laser emitter into the SMB127 mounting block, through any of the three holes.
- 2. Make sure that the label area of the emitter is not aligned with a set screw.
- 3. Tighten the set screws, using the supplied 3/64-in Allen wrench, so that the emitter is held snugly in place.
- 4. Mount the block to the adjustable baseplate (or to your own bracket).
- 5. Mount the bracket base using your own M5 or #10 screws or bolts.
- 6. Check for alignment (see Alignment).
- 7. Tighten or loosen one or two of the precision alignment screws, using the supplied 2 mm Allen wrench, until the laser is accurately aligned.


Wiring

Quick disconnect (QD) wiring diagrams are functionally identical.



Alignment

M12 laser emitters have a beam divergence of only 0.03° (0.5 milliradians) at 25 °C (77 °F) ambient temperature (see *Figure 2* on page 2). This translates, for example, to a beam diameter of only 8 mm (0.3 in) at a distance of 6.1 m (20 ft). Consequently, there is very little forgiveness for angular misalignment.




Opposed Distance (X)	Beam Width (W)	
1.5 m (5 ft)	3.5 mm (0.14 in)	
3 m (10 ft)	5 mm (0.2 in)	
6 m (20 ft)	8 mm (0.3 in)	
15 m (50 ft)	17 mm (0.7 in)	
30 m (100 ft)	32 mm (1.3 in)	

Figure 2. M12 laser emitter beam divergence at 25 °C (beam size vs. distance)

The beam size listed in *Figure 2* on page 2 is also the effective beam size at the receiver. The effective beam is equal to the minimum opaque object profile required to block the light beam. The beam size at the emitter is 2 mm (.08 in) diameter.

The effect of angular misalignment is dramatic. Laser emitters require their beam center to directly strike the receiver lens. *Figure 3* on page 3 shows how far the laser beam will miss the center of the receiver lens for each degree of angular misalignment (in any plane). Note that even at only a 5 ft range, one degree of misalignment causes the laser beam to miss the lens of most receivers.



Opposed Distance (X)	Beam Displacement (Y) for 1° of Misalignment	
1.5 m (5 ft)	25 mm (1 in)	
3 m (10 ft)	50 mm (2 in)	
6 m (20 ft)	100 mm (4 in)	
15 m (50 ft)	250 mm (10 in)	
30 m (100 ft)	500 mm (20 in)	

Figure 3. Beam displacement per degree of misalignment

Alignment Tip: The visible red beam of the laser emitter is easily seen in subdued lighting.

Alignment:

- 1. At opposed distances of up to 3 m (10 ft), attach a sheet of white paper directly in front of the receiver lens.
- 2. Mark the location of the lens center on the paper. Use this mark as an aiming target.
- 3. Sight along the beam from directly behind the laser emitter.
- 4. Adjust the emitter mounting until the red image (the dot of red light) is centered exactly on the mark.
- 5. Remove the paper and check the response of the receiver.

For longer distances (up to 7.6 m or 25 ft), replace the white paper with a 102 mm \times 102 mm (4 in \times 4 in) square of high-grade retroreflective tape (Banner model BRT-THG-4X4-5 or equivalent). For greater distances, use a larger sheet of retroreflective material. Never use a mirror as an alignment target.




Figure 4. At long distances, use retroreflective tape to locate the beam at the receiver location.

Specifications

Supply Voltage and Current

10 V dc to 30 V dc (10% max. ripple) at less than 30 mA

Supply Protection Circuitry

Protected against reverse polarity, transient voltages, and electrostatic discharge

Delay at Power-Up

Less than 30 milliseconds

Sensing Beam

Visible red Class 1 laser, 650 nm (temperature coefficient 0.2 nm/°C) Pulse Width: 7 μs

Rep Rate: 30 µs

Peak Output Power: 0.36 milliwatts

Beam Diameter at Aperture

Approximately 2 mm (0.08 in) diameter

Beam Placement

Within 0.25 mm (0.01 in) and ± 2 milliradians of mechanical centerline axis of housing

Beam Divergence

± 0.5 milliradians typical at 25° C; ±1.0 milliradians at operating temperature extremes

Laser Classification

Class 1 laser product; complies with 21 CFR 1040.10, EN 60825-1:2001 except for deviations pursuant to laser notice No. 50, dated 7-26-01

Laser Control

Beam enable: Apply + 10 V dc to 30 V dc to black wire Beam inhibit: Apply 0 V or by opening circuit Enable delay: Less than 30 milliseconds Inhibit delay: Less than 1 milliseconds Indicators

Indicators are visible through the rear cover Green indicates power applied Amber indicates laser enabled

Connections

2 m (6.5 ft) unterminated 3-wire PVC-jacketed high-flex cable, 9 m (30 ft) unterminated 3-wire PVC-jacketed high-flex cable, or 150 mm (6 in) PVC cable with a 3-pin M8/Pico-style male quick disconnect (QD)

Construction

12.7 mm (0.50 in) dimeter smooth aluminum barrel; black hard-coat anodized finish

MIL-A-8625 Type III, Class II

Operating Temperature

0 °C to +40 °C (+32 °F to +104 °F)


90% at +40 °C maximum relative humidity (non-condensing)

Environmental Rating

NEMA 6; IEC IP67


Certifications

Product Labe



Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.



Excess Gain

The Excess Gain of the M12 emitter is dependent on the particular receiver used. The following is a comparison of the excess gain for various recommended receivers at 15 m (50 ft).

Receiver	Excess Gain at 15 m (50 ft)		
MULTI-BEAM			
SBRX1	1,900		
SBR1	1,900		
SBRXD1	1,900		
SBRD1	1,900		
MAXI-BEAM			
RSBR	1,400		
RSBRSR	150		
VALUE-BEAM			
SMW95R	3,400		
SMI91RQD	1,800		
EZ-BEAM			
T18SN6R	750		
T30SN6R	750		
S12SN6R	750		

Receiver	Excess Gain at 15 m (50 ft)			
MINI-BEAM				
SM31R	250			
SM31RL	1,700			
SM31RMHS	180			
SM31RLMHS	1,100			
ECONO-BEAM				
SE61R	60			
SE61RMHS	50			
Others				
SM51RB	120			
Q23SN6R	40			
Q10AN6R	25			
Q45BB6R	900			


For information on compatibility of the M12 emitter with other Banner photoelectric receivers contact Banner Engineering.

Accessories

Mounting Brackets

SMB46X3


- Assembly with mounting block and adjustable bracket
- Includes:
 - 2 mm Shortarm hex key 3/64-in Shortarm hex key 4 Set screws



SMB127

- Mounting block only
- Includes:

3/64-in Shortarm hex key 4 Set screws



Quick-Disconnect Cables

3-Pin Threaded M8/Pico-Style Cordsets				
Model	Length	Style	Dimensions	Pinout (Female)
PKG3M-2	2 m (6.56 ft)			4
PKG3M-5	5 m (16.40 ft)			1
PKG3M-7	7 m (22.97 ft)	Straight	ø 9.5	3- 0
PKG3M-9	9 m (29.53 ft)		M8 x 1	1 = Brown
PKG3M-10	10 m (32.81 ft)		III A I	3 = Blue 4 = Black

Retroreflective Tape

Model	Reflectivity Factor	Maximum Temperature	Size
BRT-THG-4X4-5	0.7	+60 °C (+140 °F)	100 × 100 mm (package of 5)

Model	Reflectivity Factor	Maximum Temperature	Size
BRT-THG-8.5X11-2	0.7	+60 °C (+140 °F)	216 × 280 mm (package of 2)

Model	Reflectivity Factor	Maximum Temperature	Size
BRT-THG-18X36	0.7	+60 °C (+140 °F)	457 × 914 mm (single sheet)

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.