

Sensor Error Codes

- Please note the software version on the Sensor and the GUI. This can help with further debugging.
- Please save the error log to your hard drive. This can be used to help debug if necessary.
- Please reset the system error flag and error log after you have saved the error log to your hard drive. The error LED will stay active until you clear the error condition error flag. The error flag can be reset in the Reset tab in System.

NOTE: Possible solutions in numbered lists indicate the order in which solutions should be exercised.

Error Code	User Description	Possible Solutions
0	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
1	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
2	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
3	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
4	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
5	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
6	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
7	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
8	Potential noise, corrupted firmware, or hardware failure	<ol style="list-style-type: none"> 1. Check connections. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
9	I/O short circuit detected	<ol style="list-style-type: none"> 1. Check all I/O line connections for possible short. 2. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
10	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
11	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
12	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
13	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
14	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
15	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
16	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
17	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
18	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
19	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
20	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
21	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
22	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
23	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.
24	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persists. 2. If problem continues to persist, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
25	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
26	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
27	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persist. 2. If problem continues to persist, please call your local Banner representative.
28	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
29	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persist. 2. If problem continues to persist, please call your local Banner representative.
30	System timer error	<ol style="list-style-type: none"> 1. Do nothing, but reboot Sensor if issue persist. 2. If problem continues to persist, please call your local Banner representative.
31	Potential corrupted firmware or hardware failure. Peripheral bus parity error has occurred.	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
32	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
33	System TickAnnounce Registration Failed	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
34-99	NOT USED	--
100	System Error Log exceeded: Ignoring further errors	<ol style="list-style-type: none"> 1. Clean old errors. 2. If problem persists, please call your local Banner representative.
101	File system full: Ignoring further errors	<ol style="list-style-type: none"> 1. Clean old errors. 2. If problem persists, please call your local Banner representative.
102	System error: display_info - out of memory	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
103-199	NOT USED	--
200	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
201	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
202	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
203	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
204	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
205	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
206	Potential corrupted firmware or Hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
207	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
208	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
209	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
210	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
211	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
212	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
213	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
214	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
215	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
216	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
217	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
218	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
219-221	NOT USED	--
222	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
223	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
224	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
225	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
226	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
227	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
228	-IO Pin out of range	<ol style="list-style-type: none"> 1. Check I/O line configuration data. 2. If problem persists, please call your local Banner representative.
229	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Restart inspection. 2. Rebuild inspection. 3. Reboot Sensor. 4. If problem persists, please call your local Banner representative.
230	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
231	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
232	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
233	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
234	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Try adjusting gain and exposure settings. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
235	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Try adjusting gain and exposure settings. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
236	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Try adjusting gain and exposure settings. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
237	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Try adjusting gain and exposure settings. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
238	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Try adjusting gain and exposure settings. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
239	File does not exist; corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
240	File contains wrong data; corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
241	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
242	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
243	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
244	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
245	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
246	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
247	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
248	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
249	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
250	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
251	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
252	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
253	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
254	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
255	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
256	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
257	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
258	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
259	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
260	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
261	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
262	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
263	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
264	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
265	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
266	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
267	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
268	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
269	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
270	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
271	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
272	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
273	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
274	Wrong input data	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
275-285	NOT USED	--
286	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
287	Wrong input data	<ol style="list-style-type: none"> 1. Check I/O line configuration. 2. Reboot Sensor. 3. Reboot Sensor. 4. If problem persists, please call your local Banner representative.
288	Wrong input data	<ol style="list-style-type: none"> 1. Check I/O line configuration. 2. Reboot Sensor. 3. Re-install firmware. 4. If problem persists, please call your local Banner representative.
289-292	NOT USED	--

Sensor Error Codes

Error Code	User Description	Possible Solutions
293	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
294	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
295	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
296	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
297	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
298	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
299	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
300	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
301	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
302	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
303	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
304	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
305	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
306	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
307	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
308	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
309	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
310	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
311	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
312	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
313	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
314	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
315	Potential corrupted firmware or hardware failure	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
316	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
317	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
318	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
319	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
320-399	NOT USED	--
400	Attempted to start an inspection while previous inspection still running	<ol style="list-style-type: none"> 1. Stop currently-executing inspection. 2. Reboot Sensor. 3. If problem persists, please call your local Banner representative.
401	NOT USED	--
402	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
403-404	NOT USED	--
405	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
406	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
407	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
408	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
409	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
410	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
411	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
412	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
413	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
414	Inspection not found. Attempting to start inspection number 0.	<ol style="list-style-type: none"> 1. Place inspection at this location . 2. Check Product Start-Up setting in GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
415	Inspection not found. Attempting to start inspection number 1.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
416	Inspection not found. Attempting to start inspection number 2.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
417	Inspection not found. Attempting to start inspection number 3.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
418	Inspection not found. Attempting to start inspection number 4.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
419	Inspection not found. Attempting to start inspection number 5.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
420	Inspection not found. Attempting to start inspection number 6.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
421	Inspection not found. Attempting to start inspection number 7.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
422	Inspection not found. Attempting to start inspection number 8.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
423	Inspection not found. Attempting to start inspection number 9.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
424	Inspection not found. Attempting to start inspection number 10.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
425	Inspection not found. Attempting to start inspection number 11.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
426	Inspection not found. Attempting to start inspection number 12.	<ol style="list-style-type: none"> 1. Place inspection at this location. 2. Check Product Select. 3. Check Product Start-Up setting in GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
427	Inspection not found. Attempting to start inspection number 13.	<ol style="list-style-type: none"> 1. Check Product Select. 2. Check Product Start-Up setting in GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
428	Inspection not found. Attempting to start inspection number 14.	<ol style="list-style-type: none"> 1. Check Product Select. 2. Check Product Start-Up setting in GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
429	Inspection not found. Attempting to start inspection number 15.	<ol style="list-style-type: none"> 1. Check Product Select. 2. Check Product Start-Up setting in GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
430	Inspection not found. Attempting to start inspection number 16.	<ol style="list-style-type: none"> 1. Check Product Select. 2. Check Product Start-Up setting in GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
431-499	NOT USED	--
500	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
501-503	NOT USED	--

Sensor Error Codes

Error Code	User Description	Possible Solutions
504	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
505-506	NOT USED	--
507	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
508-599	NOT USED	--
600	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
601-699	NOT USED	--
700	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
701	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
702	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
703	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
704	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
705	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
706	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
707	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
708	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
709	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
710	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
711	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
712	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
713	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
714	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
715	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
716	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
717	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
718	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
719	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
720	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
721	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
722	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
723	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
724	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
725	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
726	Serial communications error	<ol style="list-style-type: none"> 1. Check serial communication link between Sensor and PC. 2. Check Sensor serial settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
727	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
728	Corrupted firmware	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
729	Network stack communications error	<ol style="list-style-type: none"> 1. Check network communication link between Sensor and PC. 2. Check Sensor network settings. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
730-799	NOT USED	--
800	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
801	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
802	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
803	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
804	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
805	Error occurred during firmware update	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
806	Unable to load System Config File	<ol style="list-style-type: none"> 1. Retry firmware update without rebooting Sensor. 2. If problem persists, please call your local Banner representative.
807-899	NOT USED	--
900	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
901	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
902	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
903	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
904	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
905	Hardware error	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
906	NOT USED	--
907	I2C-read hang up	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
908	I2C-read hang up	<ol style="list-style-type: none"> 1. Reboot Sensor. 2. Re-install firmware. 3. If problem persists, please call your local Banner representative.
909-1000	NOT USED	--
1001	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1002	NOT USED	--
1003	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1004	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative
1005	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.
1006	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1007	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.
1008	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1009	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1010	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1011	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1012	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1013	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1014	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1015	Command sent to Sensor failed.	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1016	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1017	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1018	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1019	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1020	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1021	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1022	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1023	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1024	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Check communication link to Sensor. 2. Restart GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
1025	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1026	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1027	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1028	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1029	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1030	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1031	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1032	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1033	NOT USED	--
1034	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1035	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1036	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Check communication link to Sensor. 2. Restart GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1037	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Check communication link to Sensor. 2. Restart GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
1038	Failure during transfer of data between GUI and Sensor	<ol style="list-style-type: none"> 1. Check communication link to Sensor. 2. Restart GUI. 3. Reboot Sensor. 4. Re-install firmware. 5. If problem persists, please call your local Banner representative.
1039	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1040	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1041	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1042	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1043	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1044	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1045	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1046	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1047	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1048	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1049	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1050	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1051	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1052	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1053	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1054	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1055	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1056	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1057	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1058	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1059	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1060	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1061	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1062	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1063	NOT USED	--
1064	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1065	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1066	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1067	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1068	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1069	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1070	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1071	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.
1072	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.
1073	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1074	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1075	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1076	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1077	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1078	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1079	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1080	NOT USED	--
1081	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1082	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1083	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1084	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1085	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1086	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1087	NOT USED	--
1088	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1089	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1090	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1091	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1092	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1093	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1094	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1095	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1096	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1097	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1098	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1099	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1100	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1101	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1102	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1103	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1104	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1105	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1106	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1107	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1108	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1109	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1110	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1111	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1112	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1113	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1114	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1115	NOT USED	--
1116	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1117	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1118	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1119	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1120	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1121	Command sent to Sensor failed.	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1122	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1123	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1124	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1125	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1126	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1127	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1128	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1129	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1130	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1131	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1132	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1133	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1134	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1135	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1136-1137	NOT USED	--
1138	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1139	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1140-1042	NOT USED	--
1143	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1144	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1145	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1146	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1147	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1148	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1149	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1150	Command sent to Sensor failed.	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1151	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1152	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1153	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1154	Quick teach failed since one or more tools within the inspection failed	<ol style="list-style-type: none"> 1. Check all location tools to make sure they find the intended location points. 2. Make sure all other tool ROIs are as intended.
1155	NOT USED	--
1156	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1157	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1158	Timed out during quick teach	<ol style="list-style-type: none"> 1. Examine all tools for valid settings. 2. Attempt Quick Teach again. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1159	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1160	NOT USED	--
1161	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1162	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1163	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1164	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1165	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1166	GUI is executing in a corrupted state	<ol style="list-style-type: none"> 1. Restart GUI. 2. Reboot PC. 3. Re-install GUI. 4. If problem persists, please call your local Banner representative.
1167	NOT USED	--
1168	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1169	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1170	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1171	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1172	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1173	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1174	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1175	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1176	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1177	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1178	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1179	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1180	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1181	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1182	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1183	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1184	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1185	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1186	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1187	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1188	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1189	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1190	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1191	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1192	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1193	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1194	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1195	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1196	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1197	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1198	Command sent to Sensor failed	<ol style="list-style-type: none"> 1. Retry action. 2. Check communication link to Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1199	Communication failure between GUI and Sensor	<ol style="list-style-type: none"> 1. Check connection. 2. Verify IP address settings of both PC and Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1200	Communication failure between GUI and Sensor	<ol style="list-style-type: none"> 1. Check connection. 2. Verify IP address settings of both PC and Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1201	Communication failure between GUI and Sensor	<ol style="list-style-type: none"> 1. Check connection. 2. Verify IP address settings of both PC and Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1202	Failure during creation of local temporary file	<ol style="list-style-type: none"> 1. Make sure enough hard disk space is available on PC. 2. Restart GUI. 3. Reboot PC. 4. If problem persists, please call your local Banner representative.
1203	Communication failure between GUI and Sensor	<ol style="list-style-type: none"> 1. Check connection. 2. Verify IP address settings of both PC and Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.
1204	Failure during creation of local temporary file	<ol style="list-style-type: none"> 1. Make sure enough hard disk space is available on PC. 2. Restart GUI. 3. Reboot PC. 4. If problem persists, please call your local Banner representative.
1205	Communication failure between GUI and Sensor	<ol style="list-style-type: none"> 1. Check connection. 2. Verify IP address settings of both PC and Sensor. 3. Restart GUI. 4. Reboot Sensor. 5. Re-install firmware. 6. If problem persists, please call your local Banner representative.

Sensor Error Codes

Error Code	User Description	Possible Solutions
1206	Communication failure between GUI and Sensor	<ol style="list-style-type: none">1. Check connection.2. Verify IP address settings of both PC and Sensor.3. Restart GUI.4. Reboot Sensor.5. Re-install firmware.6. If problem persists, please call your local Banner representative.
1207	Command sent to Sensor failed	<ol style="list-style-type: none">1. Retry action.2. Check communication link to Sensor.3. Restart GUI.4. Reboot Sensor.5. Re-install firmware.6. If problem persists, please call your local Banner representative.